



APEL
PUNE PRODUCTS INDIA

EDITION 2026

PRODUCT CATALOGUE

Service spares for commercial vehicles

HCV

ICV

LCV



APEL PUNE PRODUCTS INDIA

Commercial vehicle spare parts

SINCE 1986

EN	ENGINE Caps, thermostats, pipes, gaskets, pulleys, fans	1-18	GR	GEARBOX Selector shafts, synchro kits, levers	19-31
CL	CLUTCH Repair kits, fork shafts, thrust rods	32-35	BR	BRAKE Rollers, slack adjusters, cam bush kits	36-41
AC	ACCELERATOR Pedal assemblies, ends, springs	42	DF	DIFFERENTIAL Oil seals, cage cups, side gears	43-45
ST	STEERING Reservoirs, arms, brackets	46-48	AX	FRONT & REAR AXLE King pin kits, axle parts, anti-roll bar kits	49-51
PS	PROPELLER SHAFT Centre bearings, brackets, nuts	52-53	AP	AIR COMPRESSOR Gasket sets, unions, fittings	54-58
FU	FUEL SYSTEM Filter switches, pump kits, strainers	59	EL	ELECTRICAL & ACCESSORIES Brackets, gear knobs, boots	60-61
DR	DOOR & CABIN Locks, handles, hinges, winders	62-64	FS	FASTENERS Head, rod, flywheel and axle bolts	65-68
CB	CONTROL CABLES Accelerator, clutch, gear cables	69-70	MS	MISCELLANEOUS Straps, jack kits, wheel safety kits	71-74
IX	CROSS-REFERENCE INDEX Look up any reference number	75-85			

HOW TO READ A PART CODE

APL-EN-104 → APL (Apel) · EN (group code, shown left) · 104 (item number). The grey tag on each card shows vehicle fitment. Red tags show the pack quantity. Use the cross-reference index at the back to find the Apel code for a reference number.



APL-EN-101 UNIVERSAL

Radiator Cap (42 Dia)



APL-EN-102 UNIVERSAL

Radiator Cap (Double Seal) (42 Dia)



APL-EN-103 UNIVERSAL

Radiator Cap (Stainless Steel) (42 Dia)



APL-EN-104 T.C.

Oil Filler Cap (Plastic) with Ring



APL-EN-105 ACE

Radiator Cap (31 Dia)



APL-EN-106 ACE

Radiator Cap (Stainless Steel) (31 Dia)



APL-EN-107 1616/3718

Coolant Tank Cap



APL-EN-108 1616

Coolant Tank Cap



APL-EN-109 407/709/1613 T.C.

Oil Filler Cap



APL-EN-110 312/407/608

Tappet Oil Cap



APL-EN-111 BS III

Tappet Cap



APL-EN-112 2518/3718

D. E. F. Tank Cap



10 PCS

APL-EN-113 1312/407/608

Timing Oil Plug



10 PCS

APL-EN-114 1612

Coolant Tank Cap



10 PCS

APL-EN-115 T.C.

Magnetic Drain Bolt for Engine Oil Sump



10 PCS

APL-EN-116 1613/407/608

Magnetic Drain Bolt for Engine Oil Sump



APL-EN-117 1210 SE/1312/407

Cylinder Head Seating Washer



APL-EN-118 1210 SE/407/709

Crank Spacer (Cut)



10 SETS

APL-EN-119 1210 SE/407/709

Fly Wheel Lock Plate Set of 4 Pcs.



10 PCS

APL-EN-120 1613/407/608

Plug Adaptor for Engine Oil Sump



APL-EN-121 T.C.

Assembly Timing Breather without Cap



APL-EN-122 / EX

Assembly Timing Breather with Cap



APL-EN-123 BS III

Crank Case Breather



APL-EN-124 BS III

Timing Breather (Sensor)



APL-EN-125 1210 SE

Oil Filler Assembly



APL-EN-126 1613 TURBO/2515

Oil Separator Assembly



APL-EN-127 1612/1109

Coolant Tank Assembly



APL-EN-128 T.C.

Coolant Tank Assembly



APL-EN-129 1210 SE/407/709

Temperature Sender Unit (M14 X1.5)



APL-EN-130 T.C.

Temperature Sender Unit



APL-EN-131 2515 T.C.

Fuel Strainer Thick - Thin



APL-EN-132 2515 EX

Fuel Strainer Thin - Thin



APL-EN-133 1210 SE

Nozzle Washer Set of 18 Pcs.




APL-EN-134 BS II

Nozzle Washer Set of 18 Pcs.



APL-EN-135 BS III

Nozzle Washer Set



APL-EN-136 BS IV

Nozzle Washer Set



APL-EN-137 TATA / LEYLAND

Air Cleaner Assembly



APL-EN-138 TATA / LEYLAND

Air Cleaner Assembly Cover



APL-EN-139 2515 EX

Fuel Strainer Pipe Set (Thin / Thin)



APL-EN-140 2515 T.C.

Fuel Strainer Pipe Set (Thick / Thin)



APL-EN-141 BS II

Belt Tensioner Assembly



APL-EN-142 BS III

Belt Tensioner Assembly



APL-EN-143 BS II

Fan Support Assembly



APL-EN-144 / BS III

Fan Support Assembly



APL-EN-145 T.C.

Timing Shaft & Bearing Kit



APL-EN-146 T.C.

Timing Shaft (Rotary Pump)



APL-EN-147 T.C.

Timing Shaft Bearing



APL-EN-148 T.C.

Coupling Rubber for Timing Shaft



APL-EN-149 BS II

Nozzle Cooling Kit



APL-EN-150 / BS II

Nozzle Cooling Spray



APL-EN-151 BS II

Bolt for Nozzle Cooling Spray



APL-EN-152 709/1109

Nozzle Cooling Spray



APL-EN-153 709

Intermediate Flange With Throttle Valve



APL-EN-154 1613T.C.

Intermediate Flange With Throttle Valve



APL-EN-155 BS II/BS III

Adopter for Turbo Plumbing



APL-EN-156 1109/1613/2515

Rotary Pump Bracket



APL-EN-157 709/1109

Manifold Elbow (3715)



APL-EN-158 / 709/1109

Manifold Elbow (3723)



APL-EN-159 709/1109

Manifold Elbow (3720)



APL-EN-160 407 SFC BS IV

EGR Cooler & Common Rail Mounting



APL-EN-161 4018

Viscous Disconnection 6 Hole (Steel)



APL-EN-162 3118

Viscous Disconnection 4 Hole (Steel)



APL-EN-163 T.C.

Viscous Disconnection 6 Hole (Steel)



APL-EN-164 T.C.

Viscous Disconnection 4 Hole (Steel)



APL-EN-165 4018

Viscous Disconnection 6 Hole (Aluminium)



APL-EN-166 3118

Viscous Disconnection 4 Hole (Aluminium)



APL-EN-167 T.C.

Viscous Disconnection 6 Hole (Aluminium)



APL-EN-168 T.C.

Viscous Disconnection 4 Hole (Aluminium)



APL-EN-169 4018

Viscous Disconnection 6 Hole (Steel)



APL-EN-170 3118

Viscous Disconnection 4 Hole (Steel)



APL-EN-171 T.C.

T - Bolt Hose Clamp (SLTB 64)



APL-EN-172 T.C.

T - Bolt Hose Clamp (SLTB 72)




APL-EN-173 T.C.

T - Bolt Hose Clamp (SLTB 80)



APL-EN-174 T.C.

T - Bolt Hose Clamp (SLTB 84)



APL-EN-175 T.C.

T - Bolt Hose Clamp (SLTB 102)



APL-EN-176 / 407

Engine Mounting Bracket



APL-EN-177 709/1109

Engine Mounting Bracket



APL-EN-178 1613 TURBO

Engine Mounting Bracket



APL-EN-179 1613/2518

Engine Mounting Bracket



APL-EN-180 3118

Engine Mounting Bracket



6 PCS

APL-EN-181

1612

Air Cleaner Adjusting Bolt with Wing Nut



10 PCS

APL-EN-182

BS II

Plug Expansion for Rocker Lever



APL-EN-183

BS II

Service Indicator Assembly



10 PCS

APL-EN-184

BS II/BS III

Timing Pin (Nylon) with 'O' Ring



APL-EN-185

BS II/BS III

Timing And Main Bearing Oilseal Kit



APL-EN-186

BS II

Valve Seal Set of 12 Pcs.



APL-EN-187

BS III

Valve Seal Set of 24 Pcs.



APL-EN-188

BS IV

Valve Seal Set Of 24 Pcs.



APL-EN-189

1612/1616

Air Compressor Sleeve (94mm)



APL-EN-190

BS II

Air Compressor Sleeve (70 mm)



APL-EN-191

709/1109

Air Compressor Sleeve (77mm)



APL-EN-192

BS II/BS III

Oil Pump Assembly



APL-EN-193

1616

Air Compressor Sleeve Modified (94mm)



APL-EN-194

T.C.

Air Compressor Sleeve Modified(70mm)



APL-EN-195

709/1109

Air Compressor Sleeve Modified (77 mm)



APL-EN-196

BS III

Air Compressor Head Pipe



APL-EN-197

1613/2515

Radiator Dumble



APL-EN-198

1613 TURBO

Radiator Patti Set of 4 Pcs. (Black)



APL-EN-199

1613 TURBO

Radiator Bracket



APL-EN-200

709/1109

Radiator Mouth



APL-EN-201

1612

Thermostat Assembly (Brass)



APL-EN-202

1613 TURBO

Thermostat Assembly (Brass)



APL-EN-203

407

Thermostat Assembly (Brass)



APL-EN-204

/ 709/1109

Thermostat Assembly (Brass)



APL-EN-205

1612

Thermostat Assembly (Plastic)



APL-EN-206

1613 TURBO

Thermostat Assembly (Plastic)



APL-EN-207

407 TURBO

Thermostat Assembly (Plastic)



APL-EN-208

709/1109

Thermostat Assembly (Plastic)



APL-EN-209

1612

Thermostat Assembly with Valve (Brass)



APL-EN-210

1613 TURBO

Thermostat Assembly with Valve (Brass)



APL-EN-211

407

Thermostat Assembly with Valve (Brass)



APL-EN-212

909/1109 EX

Thermostat Assembly (Plastic)



APL-EN-213

BS II

Thermostat Valve



APL-EN-214

BS III

Thermostat Valve



APL-EN-215

BS IV

Thermostat Valve



APL-EN-216

909/1109 EX

Thermostat Assembly (Brass)



APL-EN-217

BS III

Radiator Mounting Kit



APL-EN-218

BS III

Radiator Mounting Kit (Intercooler)



APL-EN-219

LPK 2516/2518

Radiator Mounting Kit



APL-EN-220

BS II/BS III

Crank Sleeve



10 PCS

APL-EN-221

1210 SE/407/709

Screw with Nut for Rocker Lever



10 PCS

APL-EN-222

BS II

Screw with Nut for Rocker Lever



10 PCS

APL-EN-223

BS III/BS IV

Screw With Nut For Rocket Lever



APL-EN-224

BS III/BS IV

Rocker Assembly



APL-EN-225

1210 SE/1312/709


Engine Valve Collet Set of 24 Pcs.



APL-EN-226

BS II

Engine Valve Collet Set of 24 Pcs.



APL-EN-227

BS III/BS IV

Engine Valve Collet Set of 48 Pcs.



APL-EN-228

PRIMA

Rocker Assembly



APL-EN-229

1612/407

Valve Tappet Set of 12 Pcs.



APL-EN-230

BS II

Valve Tappet Set of 12 Pcs.



APL-EN-231

BS III/BS IV

Valve Tappet Set of 12 Pcs.



APL-EN-232

PRIMA

Valve Tappet Set of 12 Pcs.



APL-EN-233

1612/1613/709

Valve Rocker Shaft Set Of 2 Pcs.



APL-EN-234

BS II

Valve Rocker Shaft Set of 6 Pcs.



APL-EN-235

BS III/BS IV

Valve Rocker Shaft Set of 2 Pcs.



APL-EN-236

PRIMA

Valve Rocker Shaft Set of 2 Pcs.



4 PCS

APL-EN-237

1612/1613/709

Rocker Push Rod



4 PCS

APL-EN-238

BS II

Rocker Push Rod




4 PCS

APL-EN-239

BS III/BS IV

Rocker Push Rod



APL-EN-240

BS II

Valve & Compression Spring Set of 24 Pcs



APL-EN-241 2515/2516/4018

Assembly Intermediate Pipe (0132)



APL-EN-242 2515EX/1613 T.C.

Assembly Intermediate Pipe (0115)



APL-EN-243 2515/3015 T.C.

Assembly Intermediate Pipe (0104)



APL-EN-244 / 1613 LP

Assembly Intermediate Pipe (0102)



APL-EN-245 2518

Assembly Intermediate Pipe (0110)



APL-EN-246 2518/3718

Assembly Intermediate Pipe (0117)



APL-EN-247 1613 TURBO

Assembly Intermediate Pipe (0136)



APL-EN-248 T.C.

Assembly Intermediate Pipe (0138)



APL-EN-249 1513/1313 BUS

Assembly Intermediate Pipe (0106)



APL-EN-250 / 1613 TURBO

Assembly Intermediate Pipe (0107)



APL-EN-251 1613 TURBO/2515 EX

Assembly Intermediate Pipe (0125)



APL-EN-252 1613 TURBO

Assembly Intermediate Pipe (0123)



APL-EN-253 LPT 2518/3118/4018

Assembly Intermediate Pipe (0109)



APL-EN-254 3118

Assembly Intermediate Pipe (0117)



APL-EN-255 / 1616

Assembly Intermediate Pipe (0101)



APL-EN-256 ALL

Intermediate Pipe Connection



APL-EN-257 709

Assembly Intermediate Pipe



APL-EN-258 1109

Assembly Intermediate Pipe



APL-EN-259 909/1109 EX

Assembly Intermediate Pipe



APL-EN-260 407/709

Oil Dipstick



APL-EN-261 1612

Water Cooling Line



APL-EN-262 1613

Water Cooling Line



APL-EN-263 1613 TURBO

Water Cooling Line



APL-EN-264 / 1616

Water Cooling Line



APL-EN-265 2515 EX

Water Cooling Line



APL-EN-266 1616

Water Cooling Line (Sensor)



APL-EN-267 2416

Water Cooling Line



APL-EN-268 1613/2515/3118

Engine Mounting Arm



APL-EN-269 T.C.

Radiator Pipe Small



APL-EN-270 TURBO

Radiator Pipe Big



APL-EN-271 BS III

Radiator Pipe



APL-EN-272 1613 SE

Radiator Pipe



APL-EN-273 1613 SE

Radiator Pipe



APL-EN-274 1613 TURBO

Radiator Pipe



APL-EN-275 SK 1616

Radiator Pipe



APL-EN-276 4018

Radiator Pipe



APL-EN-277 4018 T.C.

Radiator Pipe



APL-EN-278 4018 T.C.

Radiator Pipe



APL-EN-279 2516

Radiator Pipe



APL-EN-280 3516/4018

Radiator Pipe



APL-EN-281 407/709

Silencer Bellow 2.5"x 6"



APL-EN-282 407/709

Silencer Bellow 2.5" X 6" with Pipe



APL-EN-283 909/1109

Silencer Bellow 3"x 6"



APL-EN-284 909/1109

Silencer Bellow 3" X 6" with Pipe



APL-EN-285 407/709

Silencer Bellow 2.5x 6" Interlocking



APL-EN-286 407/709

Silencer Bellow 2.5x 6" Interlocking



APL-EN-287 909/1109

Silencer Bellow 3"x 6" Interlocking



APL-EN-288 909/1109

Silencer Bellow 3"x 6" Interlocking



APL-EN-289 4018/3118

Silencer Bellow 3"x 4"




APL-EN-290 PRIMA 2523/4923

Silencer Bellow 4"x6"



APL-EN-291 MAXX PIK UP/BOLERO

Silencer Bellow 2 4"x4"



APL-EN-292 BOLERO CRDI

Silencer Bellow 2 1/2" X 8"



APL-EN-293 3118

Silencer Bellow



APL-EN-294 LEYLAND U TRUCK

Silencer Bellow



APL-EN-295 AMW

Silencer Bellow



APL-EN-296 1612

Oil Pump Strainer



APL-EN-297 1613

Oil Pump Strainer



APL-EN-298 4018

Oil Pump Strainer



APL-EN-299 407

Oil Pump Strainer



APL-EN-300 709

Oil Pump Strainer



10 PCS

APL-EN-301

709/1109

Gasket for Intermediate Pipe



10 PCS

APL-EN-302

909/1109 EX

Gasket for Intermediate Pipe Big



10 PCS

APL-EN-303

709/909/1109

Silencer Gasket



10 PCS

APL-EN-304

407 TURBO

Silencer Gasket (5 Hole)



10 PCS

APL-EN-305

T.C.

Silencer Gasket



10 PCS

APL-EN-306

2515 EX

Silencer Gasket (3 Hole)



10 PCS

APL-EN-307

4018 EX

Silencer Gasket (4 Hole)



10 PCS

APL-EN-308

2518

Silencer Gasket (4 Hole)



10 PCS

APL-EN-309

BS IV

Silencer Gasket



10 PCS

APL-EN-310

T.C.

Turbo Charger Gasket



10 PCS

APL-EN-311

T.C.

Turbo Charger Gasket



10 PCS

APL-EN-312

BS IV

Turbocharger Gasket



APL-EN-313

T.C.

Valve Cover Gasket with Isolator Noise



APL-EN-314

BS II

Exhaust Manifold Gasket Set



APL-EN-315

BS III

Exhaust Manifold Gasket Set



APL-EN-316

BSIV

Exhaust Manifold Gasket Set



APL-EN-317

1612

Exhaust Manifold Gasket Set of 2 Pcs.



APL-EN-318

1613 TURBO

Exhaust Manifold Gasket Set of 2 Pcs.



10 PCS

APL-EN-319

407 TURBO

Exhaust Manifold Gasket



10 PCS

APL-EN-320

709 TURBO

Exhaust Manifold Gasket



5 PCS

APL-EN-321

T.C.

Hose Clamp (V-Band 79) Economy



APL-EN-322

T.C.

Hose Clamp (V-Band 79) S. S.



APL-EN-323

709

Hose Clamp (V-Band 64)



APL-EN-324

/ 909/1109

Hose Clamp (V-Band 80.9)



APL-EN-325

LEYLAND

Hose Clamp (V-Band 65)



APL-EN-326

AMW


Hose Clamp (V-Band 80.4)



APL-EN-327

AMW

Hose Clamp (V-Band 113.7)



5 PCS

APL-EN-328

T.C.

T - Bolt Hose Clamp (28 No.) 2"



5 PCS

APL-EN-329

T.C.

T - Bolt Hose Clamp (34 No.) 2 1/4**



5 PCS

APL-EN-330

T.C.

T - Bolt Hose Clamp (38 No.) 2 1/2"



5 PCS

APL-EN-331

T.C.

T - Bolt Hose Clamp (40 No.) 2 3/4"



5 PCS

APL-EN-332

T.C.

T - Bolt Hose Clamp (44 No.) 2 3/4"



5 PCS

APL-EN-333

T.C.

T - Bolt Hose Clamp (54 No.) 3"



5 PCS

APL-EN-334

T.C.

T - Bolt Hose Clamp (60 No.) 3 1/4"



5 PCS

APL-EN-335

T.C.

T - Bolt Hose Clamp (66 No.) 3 1/2"



5 PCS

APL-EN-336

T.C.

T - Bolt Hose Clamp (72 No.) 3 1/2"



5 PCS

APL-EN-337

T.C.III

T - Bolt Hose Clamp (76 No.) 3 3/4"



5 PCS

APL-EN-338

T.C.

T - Bolt Hose Clamp (96 No.) 4"



5 PCS

APL-EN-339

T.C.

T - Bolt Hose Clamp (112 No.) 4 1/2"



5 PCS

APL-EN-340

T.C.

T - Bolt Hose Clamp (144 No.) 5 1/2"



APL-EN-341 BS III

Exhaust Manifold Mounting Kit



10 PCS

APL-EN-342 BS III

Exhaust Manifold Sleeve



APL-EN-343 BS III

Air Compressor Stud Kit



APL-EN-344 BS III

Turbo Charger Stud Kit



APL-EN-345 BS III

Fuel Pump Stud Kit



APL-EN-346 BS III

Valve Cover Bolt With Isolator



APL-EN-347 BS III

Injector Flange Head Cap Screw



APL-EN-348 BS III

Injector Screw (Set of 6 Pcs.)



APL-EN-349 BS II

Plug Expansions Kit for Cylinder Block



APL-EN-350 BS III/BS IV

Plug Expansion Kit for Cylinder Block



APL-EN-351 BS III/BS IV

Plug Expansion Kit for Cylinder Head



APL-EN-352 BS III

Cross Head Valve Set



APL-EN-353 1512 T.C.

Oil Gauge Pipe Stick (43.5")



APL-EN-354 1613 TURBO

Oil Gauge Pipe Stick (52")



APL-EN-355 2515 EX

Oil Gauge Pipe Stick (52.6")



APL-EN-356 BS III

Injector Clamp Set



APL-EN-357 2518

Oil Gauge Pipe Stick (55")



APL-EN-358 / 2516 TC/3516

Oil Gauge Pipe Stick (59")




APL-EN-359 1613 BS III

Oil Gauge Pipe Stick (60")



APL-EN-360 3118/4018

Oil Gauge Pipe Stick (63")



10 PCS

APL-EN-361

T.C.

Air Screw for Fuel Pump



10 PCS

APL-EN-362

T.C.

10 mm Air Compressor Pipe Connector



10 PCS

APL-EN-363

T.C.

12 mm Banjo Bolt with Air Screw



10 PCS

APL-EN-364

T.C.

12 mm Banjo Bolt with Check Valve



10 PCS

APL-EN-365

T.C.

08 mm Check Valve



25 PCS

APL-EN-366

T.C.

Dowel Ring (Big)



25 PCS

APL-EN-367

/ T.C.

Dowel Ring (Small)



10 PCS

APL-EN-368

1613 TURBO

Plug Expansions for Cylinder Block



APL-EN-369

1210 SE/1312/709

Cam Cup (Aluminium) (60 mm)



10 PCS

APL-EN-370

1210 SE

Cylinder Block Plug (60mm)



10 PCS

APL-EN-371

BS II

Cylinder Block Plug (58 mm)



10 PCS

APL-EN-372

BS II/BS III

Plug Expansion (60 mm)



20 PCS

APL-EN-373

BS II

Plug Expansion (9.5mm)



20 PCS

APL-EN-374

BS II

Plug Expansion (18 mm)



20 PCS

APL-EN-375

BS II

Plug Expansion (21mm)



20 PCS

APL-EN-376

BS II

Plug Expansion (32 mm)



20 PCS

APL-EN-377

BS II

Plug Expansion (25 mm)



20 PCS

APL-EN-378

BS IV

Plug Expansion (27.5mm)



20 PCS

APL-EN-379

BS III

Plug Expansions (13mm)



20 PCS

APL-EN-380

BS III

Plug Expansions (22.6 mm)



20 PCS

APL-EN-381

BS III

Plug Expansions (26 mm)



20 PCS

APL-EN-382

BS III

Plug Expansions (38mm)



10 PCS

APL-EN-383

T.C.

Radiator Plug Big



10 PCS

APL-EN-384

T.C.

Radiator Plug Small



APL-EN-385

909/1109/1613 BS I/V

Power Steering Pulley (497/697 TCIC)



APL-EN-386

909/1109 LP/LPT BS II

Crankshaft Pulley (2 Belt)



APL-EN-387

909/1109 LP/LPT BS IV

Water Pump Pulley (497 TCIC)



APL-EN-388

/ 709/1109

Water Pump Pulley 6 PK



APL-EN-389

207 DI/709/909 LP

Water Pump Pulley 6PK (Single Belt)



APL-EN-390

909/1109 LPT

Crankshaft Pulley (Single Belt)



APL-EN-391

909/1109 LP/LPT/.C./BSII

Power Steering Pulley



APL-EN-392

407 SFC

Water Pump Pulley



APL-EN-393

T.C./BS II

Water Pump Pulley



APL-EN-394

T.C./BS

Water Pump Pulley (Casting)



APL-EN-395

T.C./BS III

Water Pump Pulley



APL-EN-396

T.C./BS III

Water Pump Pulley (Casting)



APL-EN-397

1613/2515 TURBO

Water Pump Pulley (3 Belt)



APL-EN-398

1109/1613 LPT

Water Pump Pulley (3 Belt)



APL-EN-399

1612

Power Steering Pulley (ZF)



APL-EN-400

1612

Power Steering Pulley (Rane)



APL-EN-401 T.C.
Water Pump Pulley 8 PK



APL-EN-402 BS II/BS III
Alternator Pulley 7 PK



APL-EN-403 BS II/BS III
Alternator Pulley (Double Belt)



APL-EN-404 4018
Alternator Pulley



APL-EN-405 407
Water Cooling Line



APL-EN-406 / 407 TURBO
Water Cooling Line



APL-EN-407 407 TURBO BS II
Water Cooling Line



APL-EN-408 407 BS II
Water Cooling Line



APL-EN-409 407 BS III
Water Cooling Line



APL-EN-410 909/1109 EX
Water Cooling Line



APL-EN-411 410 EX
Water Cooling Line



APL-EN-412 709
Water Cooling Line L Type



APL-EN-413 709
Water Cooling Line



APL-EN-414 709 TURBO
Water Cooling Line



APL-EN-415 709 LPT
Water Cooling Line



APL-EN-416 709 TURBO
Water Cooling Line L Type



APL-EN-417 / 1109
Water Cooling Line



APL-EN-418 1109 TURBO
Water Cooling Line



APL-EN-419 1109 N-M
Water Cooling Line L Type



APL-EN-420 1109 TURBO
Water Cooling Line L Type



APL-EN-421 712/909/1109 EX

Water Cooling Line



APL-EN-422 1109

Water Cooling Line with Patti



APL-EN-423 2515 TURBO

Fan Shroud (697 TCIC)



APL-EN-424 / 2515 T.C.

Fan Shroud



APL-EN-425 BLADE



APL-EN-426 BLADE



APL-EN-427 BLADE



APL-EN-428 BLADE



APL-EN-429 BLADE



APL-EN-430 BLADE



APL-EN-431 BLADE



APL-EN-432 BLADE



APL-EN-433 BLADE TATA EURO II/LEYLAND HOLE SIZE



APL-EN-434 BLADE TATA/L.L. 2516 T.C./3516 HOLE SIZE



APL-EN-435 BLADE LEYLAND HINO 6E HOLE SIZE



APL-EN-436 BLADE LEYLAND CARGO & IVECO HOLE SIZE



APL-EN-437 BLADE HOLE TATA 1612 SIZE



APL-EN-438 BLADE TATA 1312 (CUMMINS) HOLE SIZE



APL-EN-439 BLADE TATA 1613 T.C. TURBO HOLE SIZE



APL-EN-440 BLADE HOLE TATA 1613 T.C. SIZE



APL-EN-441 BLADE TATA EURO I/LEYLAND HOLE SIZE



APL-EN-442 BLADE 2516 T.C./3516/AMW HOLE SIZE



APL-EN-443 BLADE HOLE 2515 EX/2516 SIZE



APL-EN-444 BLADE HOLE TATA 4018 T.C. SIZE



APL-EN-445 BLADE TATA T.C. 2515 EX HOLE SIZE



APL-EN-446 BLADE HOLE TATA 3118 RING SIZE



APL-EN-447 BLADE HOLE TATA 1616 RING SIZE



APL-EN-448 BLADE HOLE LEYLAND LATEST SIZE



APL-EN-449 BLADE HOLE AMW SIZE



APL-EN-450 BLADE HOLE TATA SPACIO/ DI SIZE



APL-EN-451 BLADE TATA 1109 BIG BORE HOLE SIZE



APL-EN-452 BLADE TATA 407 TURBO/ SAFARI HOLE SIZE



APL-EN-453 BLADE EICHER 10.80/10.95 HOLE SIZE



APL-EN-454 BLADE HOLE EICHER 10.60 SIZE



APL-EN-455 BLADE EICHER 10.90/11.10 HOLE SIZE



APL-EN-456 BLADE HOLE SWARAJ MAZDA SIZE



APL-EN-457 BLADE MATADOR/MAX/TRAVELLER HOLE SIZE



APL-EN-458 BLADE HOLE 407/SUMO SIZE



APL-EN-459 BLADE 709/909/1109 TURBO HOLE SIZE



10 PCS

APL-GR-101

G.B. 30/709

Gear Box Shims Kit with Cotter Pin



10 PCS

APL-GR-102

G.B. 40

Gear Box Shims Kit



APL-GR-103

G.B. 40

Main Drive Gear Check Nut Set



APL-GR-104

G.B. 40

Main Shaft Nut



APL-GR-105

G.B. 40

Synchronizer Kit



APL-GR-106

G.B. 40

Synchronizer Special Kit



APL-GR-107

G.B. 40

Synchronizer Special Kit for Reverse Gear



APL-GR-108

G.B. 40

1"Speed Gear Roller Set of 115 Pcs.



10 PCS

APL-GR-109

1210 SE/407/709

Oil Filling Plug for Gear & Differential



10 PCS

APL-GR-110

1210 SE

Magnetic Drain Plug for Gear Box &



APL-GR-111

G.B. 40/G.B. 50

Speedo Gear Set of 2 Pcs.



3 PCS

APL-GR-112

G.B. 40

Shifter Guide Plate



3 PCS

APL-GR-113

2515 EX/3015 EX

Gear Lever Rubber Bracket



3 PCS

APL-GR-114

1613 T.C./2416

Gear Lever Rubber Bracket



APL-GR-115

G.B. 40


End Piece for Gear Lever Rod



APL-GR-116

1613 TURBO


End Piece For Gear Lever Rod



APL-GR-117

G.B. 40

Shifting Shaft Ball & Spring Set of 12 Pcs.



10 SETS

APL-GR-118

G.B. 40/G.B. 50

Main Shaft Pin & Spring



APL-GR-119

1612

Air Breather Assembly (12 mm)



APL-GR-120

G.B. 40

Reverse Idler Shaft



APL-GR-121 1612

Gear Lever Kit



APL-GR-122 2515 EX

Gear Lever Kit



APL-GR-123 G.B. 40

Gear Lever Kit of 5 Pcs.



6 PCS

APL-GR-124 G.B. 40

Gear Lever Cup



APL-GR-125 1612

Selector Shifter Shaft Kit



APL-GR-126 G.B. 40/50/G. 600

Selector Shifter Shaft Bearing Set of 2 Pcs



10 SETS

APL-GR-127 G.B. 40/50/G. 600

Selector Shifter Shaft Oil Seal Set of 2 Pcs



10 SETS

APL-GR-128 1612

Dowel Sleeve Set of 2Pcs.



APL-GR-129 G.B. 40

Main Drive Gear Lock Kit of 2 Pcs.



10 PCS

APL-GR-130 G.B. 40/1613

Main Drive Gear Lock



10 PCS

APL-GR-131 G.B. 40

Counter Gear Circlip



10 PCS

APL-GR-132 1312

Snap Ring for 6309N / NU 309N Bearing



APL-GR-133 G.B. 40

Gear Top Cover Doom



20 PCS

APL-GR-134 G.B. 40/709 SFC

Gear Lever Pin Std.



20 PCS

APL-GR-135 G.B. 40/709 SFC

Gear Lever Pin 1" O/S.



20 PCS

APL-GR-136 G.B. 40/709 SFC

Gear Lever Pin 2" O/S



20 PCS

APL-GR-137 1210 LP

Gear Lever Pin Std.



20 PCS

APL-GR-138 1210 LP

Gear Lever Pin 1" O/S.



20 SETS

APL-GR-139 407/1210

Gear Lever Pin Std. with Lock



20 SETS

APL-GR-140 407/1210

Gear Lever Pin O/S. with Lock



APL-GR-141 G.B. 40

Selector Shaft



APL-GR-142 G. 600/709

Selector Shaft (Dumper)



APL-GR-143 G. 600

Selector Shaft (Truck)



APL-GR-144 G. 750

Selector Shaft



APL-GR-145 407 TURBO

Selector Shaft



APL-GR-146 G. 550

Selector Shaft



APL-GR-147 G. 1150

Selector Shaft



APL-GR-148 G. 950

Selector Shaft (Cable Shift)



APL-GR-149 1612

Shifter Lever (Thin Splines)



APL-GR-150 1612 T.C.

Shifter Lever (Thick Splines)



APL-GR-151 SIGMA 3718/4018 BS IV

Shifter Lever (Top Thin)



APL-GR-152 2515 EX

Shifter Lever (Top Thick)



APL-GR-153 709/1109/1613 LPT

Shifter Lever (Top Thick)



APL-GR-154 407 LP

Shifter Lever (Top Thin)



APL-GR-155 3118

Shifter Lever (Top Thick)



APL-GR-156 4018

Shifter Lever (Top Thin)



APL-GR-157 1612 T.C.

Shifter Lever J-Type



APL-GR-158 1109/G.550

Shifter Lever 'L' Type



APL-GR-159 G. 550

Shifter Lever



APL-GR-160 G. 550

Shifter Lever



10 KITS

APL-GR-161

407

Gear Box Shims Kit



APL-GR-162

407

Gear Box Overhauling Kit



10 KITS

APL-GR-163

407

Synchronizer Lock Kit of 5 Pcs.



10 SETS

APL-GR-164

407

Dowel Sleeve Set of 2 Pcs.



5 KITS

APL-GR-165

407

Counter Gear Lock Kit



10 PCS

APL-GR-166

407

Main Shaft Circlip Set of 2 Pcs.



10 PCS

APL-GR-167

407

Counter Gear Circlip



APL-GR-168

407

Gear Top Cover Mouth with Pin



APL-GR-169

407

Main Shaft Nut / Pinion Nut /



APL-GR-170

407

Main Drive Gear Check Nut Set



APL-GR-171

407

Gear Lever Kit of 5 Pcs.



6 PCS

APL-GR-172

407


Gear Lever Cup



APL-GR-173

407

Shifting Shaft Kit (Major)




10 KITS

APL-GR-174

407

Shifting Shaft Kit (Minor) Set of 3 Pcs.



10 KITS

APL-GR-175

709

Shifting Shaft Kit of 3 Pcs.



APL-GR-176

407

Reverse Dog Kit



APL-GR-177

/ 709/1109

Reverse Idler Shaft



APL-GR-178

407

Reverse Idler Shaft



APL-GR-179

207 DI

Gear Lever Kit



APL-GR-180

207 DI

Gear Box Repair Kit



10 SETS

APL-GR-181

709

Gear Lever Bolt with Nylon Bush



10 SETS

APL-GR-182

1109

Gear Lever Bolt with Nylon Bush



10 KITS

APL-GR-183

709

Gear Lever Kit of 8 Pcs. (Nylon)



10 KITS

APL-GR-184

1109

Gear Lever Kit of 8 Pcs. (Nylon)



5 KITS

APL-GR-185

709

Gear Lever Bolt with Steel Bush



5 KITS

APL-GR-186

1109

Gear Lever Bolt with Steel Bush



5 KITS

APL-GR-187

709

Gear Lever Kit of 8 Pcs. (Steel)



5 KITS

APL-GR-188

1109

Gear Lever Kit of 8 Pcs. (Steel)



APL-GR-189

709/1109

Gear Lever Plate Set of 8 Pcs.



10 SETS

APL-GR-190

709/1109

Gear Lever Bush (Nylon) with Spacer



APL-GR-191

709

Assembly Gear Lever



APL-GR-192

1109

Assembly Gear Lever



20 PCS

APL-GR-193

709

Gear Lever Bush (Nylon)



20 PCS

APL-GR-194

1109

Gear Lever Bush (Nylon)



APL-GR-195

709

Gear Bellow



APL-GR-196

709/1612

Gear Linkage Stud (6") with Nut



APL-GR-197

709/1612

Gear Linkage Stud (8") with Nut



APL-GR-198

709/1612

Gear Linkage Stud (9") with Nut



APL-GR-199

1109/1613

Gear Linkage Rod (10") with Nut



APL-GR-200

1109

Gear Linkage Stud (12") with Nut



APL-GR-201 407

Synchronizer Kit



APL-GR-202 407

Synchronizer Special Kit



APL-GR-203 709/1109

Synchronizer Kit



APL-GR-204 709/1109

Synchronizer Special Kit



APL-GR-205 ULTRA 912/812/712/1017

Synchronizer Kit (G.550)



APL-GR-206 207 DI

Synchronizer Kit



APL-GR-207 709

Selector Shaft Kit



APL-GR-208 709/1109

Gear Top Cover Kit



APL-GR-209 / 709/1109

Speedo Gear Cover



APL-GR-210 407/709

Air Breather Assembly (10mm)



APL-GR-211 407

Speedo Gear Set of 2 Pcs.



APL-GR-212 709

Speedo Gear Set of 2 Pcs.



APL-GR-213 407 SFC

Gear Lever



APL-GR-214 ULTRA 912/812/712/1017

Gear Lever (G.550)



APL-GR-215 407 LPT/909 LP

Gear Lever



APL-GR-216 709 LPT

Gear Shift Lever Bracket (Power Steering)



APL-GR-217 / 709

Gear Shift Lever Bracket (Bush Type)



APL-GR-218 709/1109 LPT

Gear Shift Lever Bracket



APL-GR-219 1109

Gear Shift Lever Bracket (Big)



APL-GR-220 1109

Gear Shift Lever Bracket (Small)



10 KITS

APL-GR-221 G. 600

Gear Box Shims Kit



10 KITS

APL-GR-222 G. 750

Gear Box Shims Kit



APL-GR-223 G. 600

Main Shaft Nut



APL-GR-224 G. 750

Main Shaft Nut



APL-GR-225 G. 600

Detent Kit



APL-GR-226 G. 600

Detent Kit of 4 Pcs.



APL-GR-227 G. 600

Detent Kit of 7 Pcs.



APL-GR-228 G. 600

Gear Lever Kit



APL-GR-229 G. 600

Gear Top Cover Needle Roller Set



APL-GR-230 G. 600

Main Drive Gear Trust Bearing



10 SETS

APL-GR-231 709/G. 600

Dowel Sleeve Set of 2 Pcs.



10 PCS

APL-GR-232 G.600

Spiral Pin for Shifter Shaft



10 PCS

APL-GR-233 G. 600

Plug for Shifter Shaft Rear



APL-GR-234 G. 600

Pivot Pin (Top Cover)



APL-GR-235 G. 750

Pivot Pin (Top Cover)



APL-GR-236 G. 600

Gear Shifting Yoke



APL-GR-237 G. 600

Speedo Gear Cover



APL-GR-238 G. 600 N-M

Speedo Gear Cover



APL-GR-239 / G. 750

Speedo Gear Cover



APL-GR-240 G. 600

Reverse Idler Shaft




APL-GR-241 G. 600

Synchronizer Kit



APL-GR-242 G. 750

Synchronizer Kit



APL-GR-243 / G.1150

Synchronizer Kit



APL-GR-244 G. 600

Shifter Fork Brass Pad Set of 2 Pcs.



APL-GR-245 G. 600

Main Shaft Circlip Set



APL-GR-246 G. 750

Main Shaft Circlip Set



APL-GR-247 G. 1150

Main Shaft Circlip Set



APL-GR-248 G. 750

Shifter Fork Brass Pad Set of 2 Pcs.



APL-GR-249 / G. 600/G. 750

Circlip for 4° Speed



APL-GR-250 G. 600/G.750

Circlip for 5° Speed



APL-GR-251 / G. 750

Snap Ring (Thick)



APL-GR-252 G. 600

Air Breather Assembly (14mm)



APL-GR-253 G. 550

Synchronizer Cone (1" / 2")



APL-GR-254 G. 550

Intermediate Cone (1" / 2") Carbon Lining



APL-GR-255 G. 550

Synchronizer Cone (108 Dia)



APL-GR-256 G. 550

Synchronizer Cone (96 Dia)



APL-GR-257 G. 750

Shifter Shaft (1" - 2")(7914)



APL-GR-258 G.750

Shifter Shaft (3" - 4*)(7915)



APL-GR-259 G. 750

Shifter Shaft (5" - 6*)(7916)



APL-GR-260 G.750

Shifter Shaft (Reverse)(7918)



APL-GR-261 SK 1616
Gear Lever Kit



APL-GR-262 SK 1616
Gear Top Cover Kit



APL-GR-263 SK 1616
Housing Block



APL-GR-264 SK 1616
Gear Lever Rubber Boot Kit



APL-GR-265 G. 600
Synchronizer Ring (Splines) Big



APL-GR-266 G. 600
Synchronizer Ring (Splines) Small



APL-GR-267 G. 600
Synchronizer Ring (Carbon Line) Big



APL-GR-268 G. 600
Synchronizer Ring (Carbon Line) Small



APL-GR-269 G. 600
Synchronizer Cone (Small) (48 Teeth)



APL-GR-270 G. 600
Synchronizer Cone (Big) (51 Teeth)



APL-GR-271 G. 600
Synchronizer Cone (4605)



APL-GR-272 G. 600
Synchronizer Ring (4° Speed) (4644)



APL-GR-273 G. 600
Synchronizer Ring (5° Speed) (4645)



APL-GR-274 G. 600
Engaging Gear (5° Speed) (4640)



APL-GR-275 G. 600
Shifter Sleeve 1/2/3/1 (4618)



APL-GR-276 G. 600
Engg. Gear Reverse 32T (4616)



APL-GR-277 G. 600
Engg. Gear 4°/5°/6° (4612)



APL-GR-278 G. 600
Engg. Gear 1°/2° (4615)



APL-GR-279 G. 600
Engg. Gear 3°/4° (4621)



APL-GR-280 G. 600
Speedo Gear Set of 2 Pcs.



APL-GR-281 / G. 600/4018

Main Shaft Washer



APL-GR-282 G. 600

Main Shaft Washer (Collar)



APL-GR-283 / G. 600

Main Shaft Washer (4" Gear)




APL-GR-284 G. 600

Main Shaft Spacer (Coupling flange)



APL-GR-285 G. 750

Main Shaft Washer (2 Cut)



APL-GR-286 G. 750

Main Shaft Washer (4 Cut)



APL-GR-287 G. 1150

Main Shaft Washer (A)



APL-GR-288 G. 1150

Main Shaft Washer (B)



APL-GR-289 G. 1150

Main Shaft Washer (C)



APL-GR-290 G. 1150

Main Shaft Washer (Plain)



APL-GR-291 G. 1150

Main Shaft Washer (Collar Type)



APL-GR-292 G. 1150

Main Shaft Washer



APL-GR-293 G. 600

Shifter Shaft (1" - 2") 7908



APL-GR-294 G. 600

Shifter Shaft (3" - 4") 7910



APL-GR-295 G. 600

Shifter Shaft (5" - 6") 7907



APL-GR-296 G. 600

Shifter Shaft (Reverse) 7909



APL-GR-297 G. 600

Gear Fork (5125) 1 1/2" / 3" / 4"



APL-GR-298 G. 600

Gear Fork (5127) 5" / 6"



APL-GR-299 G. 600

Gear Fork (5113) Reverse



APL-GR-300 G. 600

Gear Fork (5126) 5" / 6"



APL-GR-301 G. 600/709/1109

Top Cover Assembly (0130)



APL-GR-302 G. 600

Top Cover Assembly (0126)



APL-GR-303 G. 750

Top Cover Assembly (0134)



APL-GR-304 G. 750

Top Cover Assembly (0138)



APL-GR-305 G.B. 40

Top Cover Assembly



APL-GR-306 1109

Top Cover Assembly



APL-GR-307 G. 600

Shifter Finger



APL-GR-308 G. 600/G.750

Stop Segment



APL-GR-309 G. 600

Selector Shifter Shaft Kit (Major)



APL-GR-310 G. 600

Gear Top Cover Kit



APL-GR-311 G. 1150

Gear Top Cover Kit



APL-GR-312 1612

End Piece for Assembly Turning Tube



APL-GR-313 LPT 1613/2515

Gear Lever with J. Arm



APL-GR-314 LPT 2515/2518

Gear Lever with J. Arm



APL-GR-315 2515 T.C.

Gear Lever with J. Arm



APL-GR-316 LPK 1613/2516

Gear Lever



APL-GR-317 G.B. 40

Gear Lever



APL-GR-318 1613 TURBO

Gear Lever



APL-GR-319 SK 1616

Gear Lever



APL-GR-320 LPK 2518/LPS 4018/3516

Gear Lever



APL-GR-321 G. 600

Gear Box Retainer



APL-GR-322 G. 600/G. 750

Gear Front Cover Upper



APL-GR-323 G. 600/G. 750

Gear Front Cover Lower



APL-GR-324 G. 600/G. 750

Gear Rear Cover Lower



APL-GR-325 G. 600

PT.O. Plate



APL-GR-326 G. 600

P.T.O. Plate



APL-GR-327 G. 550

Shifter Finger



APL-GR-328 G. 550

Selection Lever



APL-GR-329 G. 750

Synchronizer Ring (134 mm)(4656)



APL-GR-330 G. 750

Synchronizer Ring (132 mm)(4655)



APL-GR-331 G. 750

Assembly Synchronizer Cone



APL-GR-332 G. 750

Assembly Synchronizer Cone



APL-GR-333 G. 750

Inner Cone 1 1/2 (Carbon Lining)(4657)



APL-GR-334 G. 750

Intermediate Cone 1 1/2 (4639)



APL-GR-335 G. 750

Synchro Ring 1 1/2 (4628)



APL-GR-336 G. 750

Shifter Sleeve (4631)



APL-GR-337 G. 750

Synch. Cone 3° Speed (4653)



APL-GR-338 G. 750

Synch. Cone 4° Speed (4654)



APL-GR-339 G. 750

Synch. Cone 5°/6° (4630)



APL-GR-340 / 709/1109/G. 600

Reverse Gear Washer Set of 2 Pcs.



APL-GR-341

G. 1150

Synchronizer Ring (4613)



APL-GR-342

G. 1150

Synchronizer Ring (4614)



APL-GR-343

G. 1150

Synchronizer Cone (Straight) (4607)



APL-GR-344

G. 1150

Synchronizer Cone (26 Splines) (4611)



APL-GR-345

G. 1150

Synch. Cone 1 1/2" (38-51) (4605)



APL-GR-346

G. 1150

Synch. Cone 3 1/4" (45-51) (4606)



APL-GR-347

G. 1150

Synchro Ring (Drive Shaft) (36 X 51)



APL-GR-348

G. 1150

Sleeve (Range Set) 51 Teeth (4610)



APL-GR-349

G. 1150

Shifter Sleeve (Crawler/Rev.) 51T (4612)



APL-GR-350

G. 1150

Shifter Sleeve (Crawler/Rev.)



APL-GR-351

2515EX

Gear Shift Lever Bracket



APL-GR-352

3118

Gear Shift Lever Bracket



APL-GR-353

3118

Gear Shift Lever Bracket (Modified)



APL-GR-354

3118

Gear Shift Lever Bracket



APL-GR-355

/ LP 2518 BS III

Gear Shift Lever Bracket



APL-GR-356

3118

Gear Shift Lever Bracket



APL-GR-357

1613 TURBO

Gear Box Bracket Set (Plain) R/L



APL-GR-358

1613 TURBO

Gear Box Bracket Set (Patti) R/L



APL-GR-359

EURO III

Gear Box Bracket Right "H"



APL-GR-360

/ EURO III

Gear Box Bracket Left "H"



APL-CL-101 2515 EX

Clutch Repair Kit (352 Dia) with Bearing



APL-CL-102 2515 C/EX

Pin, Circlip & Bearing Kit (352 Dia)



APL-CL-103 2515 C/EX

Pin, Circlip & Washer Kit (352 Dia)



APL-CL-104 1613 TURBO

Clutch Repair Kit (330 Dia) with Bearing



APL-CL-105 2518/4018 EX

Clutch Repair Kit 380 Dia with Bearing



APL-CL-106 2518/4018 EX

Pin, Circlip & Bearing Kit (380 Dia)



APL-CL-107 2518/4018 EX

Pin, Circlip & Washer Kit (380 Dia)



APL-CL-108 1613 T.C./TURBO

Pin, Circlip & Bearing Kit (330 Dia)



APL-CL-109 1613 T.C./TURBO

Clutch Lever Bearing (Cage Type)



APL-CL-110 2515 EX/4018

Clutch Lever Bearing (Cage Type)



APL-CL-111 1613 T.C./TURBO

Clutch Lever Bearing (Roller Type)




APL-CL-112 2515 EX/4018

Clutch Lever Bearing (Roller Type)



APL-CL-113 1613 TURBO

Clutch Finger Pin & Bush



APL-CL-114 1612/709

Clutch and Brake Pedal Spring



APL-CL-115 1613/2515

Clutch Cylinder Bracket



APL-CL-116 1613/709

Clutch Cylinder Bracket



APL-CL-117 1613

Clutch Cylinder Bracket



APL-CL-118 LPT 3118/3718

Clutch Cylinder Bracket



APL-CL-119 407

Clutch Cylinder Bracket



APL-CL-120 1109

Clutch Cylinder Bracket



APL-CL-121 2515 T.C.

Clutch Fork Assembly



APL-CL-122 3118/4018

Clutch Fork Assembly



APL-CL-123 4018 BS IV

Clutch Fork Assembly



APL-CL-124 1616 T.C./912 BS IV

Clutch Fork Assembly



APL-CL-125 2515 T.C.

Clutch Fork Shaft with Bush & Key



APL-CL-126 2518 T.C.

Clutch Fork Shaft with Bush & Key



APL-CL-127 4018/3118 T.C.

Clutch Fork Shaft with Bush & Key



APL-CL-128 T.C.

Clutch Fork Shaft Bush & Key Kit



APL-CL-129 LPT 2518/3718

Cross Shaft with Lever (380 Dia)



APL-CL-130 2518/2523

Cross Shaft With Lever (352 Dia)



APL-CL-131 1616 T.C./912 BS IV

Cross Shaft (352 Dia Organic)



APL-CL-132 4018 BS IV

Clutch Fork Setting Kit



APL-CL-133 2515 EX

Clutch Shaft Lever



APL-CL-134 3118

Cross Shaft Lever



APL-CL-135 1613 T.C./TURBO

Collector Ring (330 Dia)




APL-CL-136 2518/4018 EX

Collector Ring (380 Dia)



APL-CL-137 2518/3118

Cross Shaft Kit (352 Dia)



APL-CL-138 2515

Clutch Pedal Spring



APL-CL-139 1109

Clutch Pedal Assembly



APL-CL-140 1109 EX

Clutch Pedal Assembly



APL-CL-141 1612/709

Clutch Patti Assembly Set



APL-CL-142 1613 TURBO

Clutch Patti Assembly Set



APL-CL-143 1613 TURBO BS III

Clutch Patti Assembly Set



APL-CL-144 407

Clutch Patti Assembly Set



APL-CL-145 1612/709

Clutch Patti Set



APL-CL-146 1613 TURBO

Clutch Patti Set



APL-CL-147 1613 TURBO BS III

Clutch Patti Set



APL-CL-148 1613 T.C.

Clutch Cylinder Push Rod Assembly



APL-CL-149 1612/709

Clutch Patti Race with Lock



APL-CL-150 T.C.

Clutch Patti Race with Lock



APL-CL-151 407/709

Clutch Cylinder Push Rod Assembly



APL-CL-152 1612/407/709

Clutch Cylinder Yoke



APL-CL-153 407

Clutch Thrust Rod Assembly (6")



APL-CL-154 407 TURBO

Clutch Thrust Rod Assembly (5")



APL-CL-155 / 407 TURBO

Clutch Thrust Rod Assembly (4")



APL-CL-156 709

Clutch Thrust Rod Assembly (6 3/4")



APL-CL-157 909

Clutch Thrust Rod Assembly (6 1/4")



APL-CL-158 1109

Clutch Thrust Rod Assembly (6 3/4")



APL-CL-159 1109 TURBO

Clutch Thrust Rod Assembly (5")



APL-CL-160 2518

Clutch Cylinder Push Rod Assembly



10 KITS

APL-CL-161

1612/1613

Clutch Pedal Kit (12 mm)



10 KITS

APL-CL-162

/ 407

Clutch Pedal Kit (10 mm)



10 KITS

APL-CL-163

/ 407

Brake Pedal Eccentric Pin Kit



APL-CL-164

407


Clutch Pedal Kit (Major)



APL-CL-165

1612/1613

Clutch & Brake Pedal Kit (Major)



APL-CL-166

709

Clutch Pedal Kit (Major)



APL-CL-167

4018

Clutch Oil Container



APL-CL-168

3118

Clutch Oil Container

10 KITS

APL-BR-101

1612

Pin Kit (Cotter Pin Type)

10 KITS

APL-BR-102

1612

Pin Kit (Head Type)


APL-BR-103

1612

Roller for Cam Shaft (38-19)


APL-BR-104

1612

Fulcrum Pin for Cam Shaft (38-22)


APL-BR-105

TATA/LEYLAND

Roller for Cam Shaft (32-19)


APL-BR-106

TATA/LEYLAND

Fulcrum Pin for Cam Shaft (32-25)


APL-BR-107

2515 EX

Roller for Cam Shaft (52-19)


APL-BR-108

2516 EX

Fulcrum Pin for Cam Shaft (52-22)


APL-BR-109

3118

Roller for Cam Shaft (35-19)


APL-BR-110

1612

Brake Cam Washer & Shims Kit Front/Rear


25 PCS
APL-BR-111

2515/2518

Brake Cam Washer Big (2 mm)


50 PCS
APL-BR-112

2515/2518

Brake Cam Washer Big (1 mm)


25 PCS
APL-BR-113

2515/2518

Brake Cam Washer Small (2mm)


50 PCS
APL-BR-114

2515/2518

Brake Cam Washer Small (1mm)


APL-BR-115

1612

Brake Oil Container with Bracket


APL-BR-116

/ 1612

Brake Oil Container


APL-BR-117

1613 T.C.

Brake Oil Container


APL-BR-118

407 TURBO

Brake Oil Container


APL-BR-119

/ 709

Brake Oil Container with Sensor


APL-BR-120

407

Brake Oil Container with Sensor


APL-BR-121 1612/1613


Diaphragm Knorr T - 20


APL-BR-122 2515/2518

Diaphragm Knorr T - 24


APL-BR-123 3118

Diaphragm Knorr T - 30



6 PCS

APL-BR-124 TATA/LEYLAND

Brake Chamber Spring


APL-BR-125 1612

Slack Adjuster Kit (Slot Type)


APL-BR-126 1612

Slack Adjuster Kit (Makhi Type)


APL-BR-127 2515 EX

Slack Adjuster Kit (HALDEX)


APL-BR-128 1612

Slack Adjuster Kit (Modified)


APL-BR-129 1613 TURBO

Slack Adjuster Kit


APL-BR-130 709/1109

Slack Adjuster Kit


APL-BR-131 1612/1613

Brake Pedal Kit (Minor)



10 PCS

APL-BR-132 4018

Palm Coupling Bush (Trailer)


APL-BR-133 1612

Brake Chamber Bracket Set (Front)


APL-BR-134 1612

Brake Chamber Bracket Set (Rear)


APL-BR-135 3515 EX

Brake Chamber Bracket Set (Front)


APL-BR-136 3515 EX

Brake Chamber Bracket Set (Rear)


APL-BR-137 T.C.

Brake Chamber Bracket (Front)


APL-BR-138 T.C.

Brake Chamber Bracket (Rear)


APL-BR-139 T.C.

Brake Chamber Bracket (TVS) Front


APL-BR-140 T.C.

Brake Chamber Bracket (TVS) Rear


APL-BR-141

3118

Brake Chamber Bracket (Rear)


APL-BR-142


709/1109

Brake Chamber Bracket (Front)


APL-BR-143

709/1109

Brake Chamber Bracket (Rear)


APL-BR-144

1612

Brake Cam Torque Plate Metal Bush


APL-BR-145

1613

Brake Chamber Bolt with Nut and Pin


APL-BR-146

2515 EX

Brake Chamber Bolt With Nut & Pin


APL-BR-147

2515 EX

Brake Chamber Bolt With Nut & Pin



10 KITS

APL-BR-148

1613

Nut & Pin Kit for Brake Chamber Bolt


APL-BR-149

1612

Brake Chamber Bracket Bolt Set of 2 Pcs.


APL-BR-150

2515 EX

Brake Chamber Bracket Bolt Set of 2 Pcs.



10 PCS

APL-BR-151

2515/2518

Brake Carrier Bolt



10 KITS

APL-BR-152

1612/1510

Nut & Pin Kit for Brake Chamber Bolt


APL-BR-153

1612

Brake Cam Shaft Overhauling Kit (TVS)


APL-BR-154

1612

Brake Cam Shaft Overhauling Kit (Kalyani)


APL-BR-155

2516/2518

Brake Cam Shaft Overhauling Kit (Meritor)


APL-BR-156

709/1109

Brake Cam Shaft Kit



10 SETS

APL-BR-157

1612

Brake Cam Oil Seal Set of 2 Pcs. (TVS)



10 SETS

APL-BR-158

1612

Brake Cam Oil Seal Set of 2 Pcs. (Kalyani)



10 SETS

APL-BR-159

2516/2518

Brake Cam Oil Seal Set of 2 Pcs. (Meritor)



10 SETS

APL-BR-160

709/1109

Brake Cam Oil Seal Set of 2 Pcs.



10 SETS

APL-BR-161 1612

Brake Cam Bush Set (Front)(TVS)



10 SETS

APL-BR-162 1612

Brake Cam Bush Set (Rear)(TVS)



10 SETS

APL-BR-163 1612

Brake Cam Bush Set (Front)(Kalyani)



10 SETS

APL-BR-164 1612

Brake Cam Bush Set (Rear)(Kalyani)



6 SETS

APL-BR-165 2516/2518

Brake Cam Bush Set (Front)(Meritor)



6 SETS

APL-BR-166 2516/2518

Brake Cam Bush Set (Rear)(Meritor)



APL-BR-167 1109

Brake Cam Bush (Brass) Set of 2 Pcs.



APL-BR-168 909/1109

Brake Cam Bush (Brass) Set of 2 Pcs.



10 SETS

APL-BR-169 1612

Brake Cam Distance Set of 2 Pcs. (TVS)



6 SETS

APL-BR-170 709

Brake Cam Distance Set of 2 Pcs.




APL-BR-171 1612

Brake Cam Bush Single Collar (Rear)



APL-BR-172 1612


Brake Cam Bush Double Collar



6 PCS

APL-BR-173 1613/2515

Brake Shoe Return Spring (BIL)



6 PCS

APL-BR-174 1613/2515


Brake Shoe Return Spring (BIL)



6 PCS

APL-BR-175 TATA/LEYLAND


Brake Shoe Return Spring (AAL)



6 PCS

APL-BR-176 TATA/LEYLAND


Brake Shoe Return Spring (Meritor)



6 PCS

APL-BR-177 YORK/FUWA


Brake Shoe Spring



6 PCS

APL-BR-178 BHARAT BENZ


Brake Shoe Spring



6 PCS

APL-BR-179 709/1109

Brake Shoe Return Spring



6 PCS

APL-BR-180 709/1109

Brake Shoe Return Spring

10 PCS

APL-BR-181
2515 EX

Brake Shoe Retaining Spring (BIL)

10 PCS

APL-BR-182
TATA/LEYLAND

Brake Shoe Retaining Spring (AAL)

10 PCS

APL-BR-183
1510/1612

Brake Shoe Retaining Spring (BIL)

10 PCS

APL-BR-184
YORK

Brake Shoe Spring

10 PCS

APL-BR-185
709/1109

Brake Shoe Retaining Spring


APL-BR-186
407/608

Brake Adjuster with Bolt


APL-BR-187
407/TURBO

Brake Adjuster with Bolt Modified


APL-BR-188
709

Brake Adjuster with Bolt Modified


APL-BR-189
407 0-M

Vacuum Brake Valve Seal Kit


APL-BR-190
407 EX/EICHER

Vacuum Brake Valve Seal Kit


APL-BR-191
709

Brake Adjuster with Bolt


APL-BR-192
407 TURBO

Brake Adjuster with Bolt


APL-BR-193
2515 EX

DDU Major Kit 3/96


APL-BR-194
2515 EX

Air Dryer Major KIT 3/75


APL-BR-195
2515 EX

DDU Filter 311700


APL-BR-196
2515 EX

Air Dryer Filter 311370


APL-BR-197
1612

Silencer for Air Dryer Assembly


APL-BR-198
2515 EX/1613

Silencer for D.D.U. Assembly


APL-BR-199
PRIMA

Silencer Air Dryer Assembly


APL-BR-200
2515 EX/1613

D.D.U. Valve



APL-BR-201 2515 EX/1613

D.D.U. Side Cover



APL-BR-202 2515 EX/1613

D.D.U. Top Cover with Fitting Kit



APL-BR-203 UNIVERSAL

Conversion Tee (12 mm to 10 mm)



APL-BR-204 UNIVERSAL

Conversion Tee (10 mm to 12 mm)



APL-BR-205 UNIVERSAL

Brass Connector 10 X 10 mm




APL-BR-206 UNIVERSAL

Brass Connector 12 X 12 mm



APL-BR-207 UNIVERSAL

Brass Connector 10 X 12mm



APL-BR-208 407

Brake Shoe Adjusting Kit (Front/ Rear)



APL-BR-209 1616/2515

Booster Bracket (70 No.)



APL-BR-210 3118

Booster Bracket (150 No.)



APL-BR-211 709/1109

Booster Bracket (90 No.)



APL-BR-212 407/709

Servo Non Return Valve with Grommet



APL-AC-101

3118

Accelerator Pedal Assembly



APL-AC-102

4018

Accelerator Pedal Assembly



APL-AC-103

2515 EX

Accelerator Pedal



APL-AC-104

709/1109

Accelerator Pedal



APL-AC-105

407/709/1109

Accelerator Pedal Assembly



APL-AC-106

SFC 407/709

Accelerator Pedal Assembly



APL-AC-107

3118

Accelerator Pedal Assembly (Sensor)



APL-AC-108

PRIMA 2523/4923

Accelerator Pedal Assy (Sensor)



10 SETS

APL-AC-109

1210 SE

Accelerator End (Gold)




10 SETS

APL-AC-110

407/1612

Accelerator End (Right) (Gold)



10 SETS

APL-AC-111

407/1612

Accelerator End (Left) (Gold)



APL-AC-112

407/709 L.P.

Accelerator Control Fork & Link Kit



20 PCS

APL-AC-113

1210 SE

Accelerator End



20 PCS

APL-AC-114

407/1612

Accelerator End (Right)



20 PCS

APL-AC-115

407/1612

Accelerator End (Left)



20 PCS

APL-AC-116

2518/3118

Accelerator Cable Lock



20 PCS

APL-AC-117

1210/1612

Accelerator Spring



10 PCS

APL-AC-118

1613 TURBO

Accelerator Spring




10 PCS

APL-AC-119

2515 EX

Accelerator Spring (Rotary Pump)



10 PCS

APL-AC-120

SFC 407/709

Accelerator Spring



APL-DF-101 LPK 2516

Thru Shaft Kit



APL-DF-102 LPK 2516

Input Shaft Kit



APL-DF-103 LPK 2516

Input Shaft Kit Rear



APL-DF-104 2518

Input Shaft Oil Seal Set of 3 Pcs.



APL-DF-105 LPK 2516

Thru Shaft Oil Seal



APL-DF-106 LPK 2516

Input Shaft Oil Seal



APL-DF-107 LPK 2516

Input Shaft Oil Seal (Rear)



APL-DF-108 2518

Thru Shaft Oil Seal



APL-DF-109 2518/4923

Thru Shaft Kit



APL-DF-110 2518/4923

Input Shaft Kit



APL-DF-111 2518/4923

Input Shaft Kit Rear



APL-DF-112 2518

Pinion Oil Seal



APL-DF-113 2518/4923

Thru Shaft Oil Seal



APL-DF-114 2518/4923

Input Shaft Oil Seal



APL-DF-115 2518/4923

Input Shaft Oil Seal (Rear)



APL-DF-116 2515 EX

Differential Shims Kit



APL-DF-117 2518

Thru Shaft Kit



APL-DF-118 2518

Pinion Kit (Forward)



APL-DF-119 2518

Pinion Kit (RWD)



APL-DF-120 2518

Input Shaft Kit



APL-DF-121 LPK 2516

Cage Cup & Cone Assembly -



APL-DF-122 LPK 2516

Cage Cup & Cone Assembly - Input Shaft



APL-DF-123 LPK 2516

Cage Cup & Cone Assembly - Pinion



APL-DF-124 2518/4923

Cage Cup & Cone Assembly - Input Shaft



APL-DF-125 LPK 2516

Cage, Cup & Cone Assembly with Oil Seal



APL-DF-126 2518/4923

Cage, Cup & Cone Assembly with Oil Seal



APL-DF-127 2518

Cage Cup & Cone Assembly - Thru Shaft



APL-DF-128 LPK 2516

Air Chamber Assembly with hardware



APL-DF-129 LPK 2516

Thru Shaft (C34 X 32)



APL-DF-130 2518/4923

Thru Shaft (C39 X 20)



APL-DF-131 2518

Thru Shaft (C26 X 35)(SRT Axle)



APL-DF-132 LEYLAND 2516/2518

Thru Shaft (C39 X 34) DANA SPICER



APL-DF-133 1210 SE

Pinion Nut



APL-DF-134 2516/2518

Input Shaft Nut



APL-DF-135 LPK 2516

Thru Shaft Nut




APL-DF-136 LPK 2516

Pinion Nut



APL-DF-137 2518

Input Shaft Nut



APL-DF-138 2518/4923

Pinion Nut



APL-DF-139 2518/4923

Input Shaft Washer



APL-DF-140 2518

Input Shaft Washer (SRT Axle)



APL-DF-141 LPK 2516

Side Gear Inter Axle (16 X 32)



APL-DF-142 2518/4923

Side Gear Inter Axle (16 X 20)



APL-DF-143 2518

Side Gear Inter Axle (16 X 35)



APL-DF-144 2518

Side Gear Inter Axle (16 X 35)



APL-DF-145 2518

Side Gear Inter Axle (16 X 21)



APL-DF-146 2518

Side Gear Inter Axle (16 X 21)



APL-DF-147 2518

Side Gear Inter Axle (16 X 21)



APL-DF-148 1612

Air Breather Assembly



APL-DF-149 LPK 2516

Nest Assembly (41 Teeth)



APL-DF-150 2518/4923

Nest Assembly (Inter Axle) (22 Teeth)



APL-DF-151 2518

Nest Assembly (Differential) (37 Teeth)



APL-DF-152 2518

Oil Pump (SRT Axle)



APL-DF-153 LPK 2516

Magnetic Drain Plug



APL-DF-154 2518/4923

Magnetic Drain Plug



APL-DF-155 2518/4923

Filler Plug



APL-DF-156 2518

Magnetic Drain Plug



APL-DF-157 LPK 2516

Clutch Collar (28 Teeth)



APL-DF-158 2518/4923

Clutch Collar (15 Teeth)



APL-DF-159 2518

Clutch Collar (21 Teeth)



APL-DF-160 2518

Pinion Spacer



APL-ST-101 ZF

Reservoir Tank Assembly



APL-ST-102 RANE

Reservoir Tank Assembly



APL-ST-103 RANE NEW

Reservoir Tank Assembly



APL-ST-104 1109/LEYLAND

Reservoir Tank Assembly RANE



APL-ST-105 RANE

Reservoir Tank Assembly



APL-ST-106 RANE

Reservoir Tank Assembly (Thread)



APL-ST-107 709/1109

Reservoir Tank Assembly ZF



APL-ST-108 709/1109

Reservoir Tank Assembly RANE



APL-ST-109 ZF

Power Steering Pump Bolt



APL-ST-110 RANE

Power Steering Pump Bolt



APL-ST-111 / 1613 TURBO

Steering Adjusting Kit



APL-ST-112 1109 VRST

Steering Adjusting Kit



APL-ST-113 1613/1109

Power Steering Pump Bracket



APL-ST-114 1613/2515

Power Steering Pump Bracket



APL-ST-115 FORNI

Power Steering Oil Gage



APL-ST-116 FORNI N-M

Power Steering Oil Gage



5 PCS

APL-ST-117 1613 VRST

Steering Sector Shaft Oil Seal (Big)



5 PCS

APL-ST-118 1613 VRST

Steering Worm Shaft Oil Seal (Small)



5 PCS

APL-ST-119 1109 VRST

Steering Sector Shaft Oil Seal (Big)



5 PCS

APL-ST-120 1109 VRST

Steering Worm Shaft Oil Seal (Small)



APL-ST-121 LPT 3118

Steering Arm RH



APL-ST-122 LPT 3118

Steering Arm LH



APL-ST-123 2523/3118/3718

Steering Arm Top



APL-ST-124 2518/3118/4018

Steering Arm Top



APL-ST-125 1613/2515

Steering Arm RH



APL-ST-126 1613/2515

Steering Arm LH



APL-ST-127 1613/2515

Steering Arm Top



APL-ST-128 LPT 3718

Tie Rod Arm RH (Lift Axle)



APL-ST-129 LPT 1109

Steering Arm RH



APL-ST-130 / LPT 1109

Steering Arm LH



APL-ST-131 LPT 1109

Steering Arm



APL-ST-132 LPT 3718

Tie Rod Arm LH (Lift Axle)



APL-ST-133 SFC 407/709/909

Tie Rod Arm RH



APL-ST-134 / SFC 407/709/909

Tie Rod Arm LH



APL-ST-135 SFC 407/709/909

Steering Arm



APL-ST-136 2515 EX

Power Steering Bolt (M18 X 50)



APL-ST-137 LPT2518/4923 PRIMA

Tie Rod Arm RH



APL-ST-138 LPT2518/4923 PRIMA

Tie Rod Arm LH



APL-ST-139 LPT 2518/4923 PRIMA

Steering Arm



APL-ST-140 LPT 2515 EX

Power Steering Bracket (Base Plate)



APL-ST-141 LPT 3118 CAB

Power Steering Bracket (Base Plate)



APL-ST-142 LPT 3118 COWL

Power Steering Bracket



APL-ST-143 LPK 2516/2518

Power Steering Bracket (Cup Type)



APL-ST-144 LPT 909

Power Steering Bracket



APL-ST-145 LPT 1109

Power Steering Bracket



APL-ST-146 1613 TURBO

Steering Plate (VRST)(3 Hole)



APL-ST-147 SE/SK 1613

Steering Plate (4 Hole)



APL-ST-148 407 TURBO

Steering Plate



APL-ST-149 2515/1613 LPT

Power Steering Bracket (3716)



APL-ST-150 1613 LP

Power Steering Bracket (3711)



APL-ST-151 2515 EX

Power Steering Bracket (3724)



APL-AX-101 1210 SE

King Pin Repair Kit



APL-AX-102 1612

King Pin Repair Kit



APL-AX-103 1613/2515

King Pin Repair Kit



APL-AX-104 PRIMA

King Pin Repair Kit



APL-AX-105 407

King Pin Repair Kit



APL-AX-106 709

King Pin Repair Kit



APL-AX-107 909 EX

King Pin Repair Kit



APL-AX-108 407/709 TURBO

King Pin Repair Kit



APL-AX-109 1109

King Pin Repair Kit



APL-AX-110 207 DI

King Pin Repair Kit



APL-AX-111 1612/2515 EX

Front Wheel Axle Shims Kit for



APL-AX-112 LPT 2518/3718

Front Wheel Axle Shims Kit



APL-AX-113 1613 TURBO

Front Spindle Lock Washer




APL-AX-114 LPS 4018

Front Spindle Lock Washer



APL-AX-115 PRIMA 2523/4923

Front Spindle Lock Washer



APL-AX-116 407/709/1109

Front Wheel Axle Shims Kit for



APL-AX-117 709

Front Spindle Lock Washer



APL-AX-118 1109

Front Spindle Lock Washer



APL-AX-119 2518/3718 BS IV

Front Spindle Lock Washer



APL-AX-120 1613/2515

King Pin Cup



APL-AX-121 LPT3118

Kit Bush Assembly Single for Lift Axle



APL-AX-122 LPT 3118

Kit Bush Assembly Single for Lift Axle



APL-AX-123 LEYLAND 3118

Kit Bush Assembly For Lift Axle



APL-AX-124 LPT 3118 / 3718

Kit Bush Assembly For Lift Axle (27 mm)



APL-AX-125 3118

Ballon Tee



APL-AX-126 3118

Lift Axle Rubber Bush



APL-AX-127 3118

Lift Axle Pin



APL-AX-128 3118

Lift Axle Washer Set of 2 Pcs.



APL-AX-129 1210/1109

Lock Washer



APL-AX-130 1612

Lock Washer



APL-AX-131 407

Lock Washer



APL-AX-132 608

Lock Washer



APL-AX-133 2515 EX

Locking Bolt for Axle Check Nut



APL-AX-134 1613 TURBO

Locking Bolt for Axle Check Nut



APL-AX-135 407/709

Rear Wheel Axle Shims Kit for



APL-AX-136 407/709

Rear Wheel Axle Shims Kit for



APL-AX-137 1612

Rear Wheel Axle Shims Kit for



APL-AX-138 2515 EX

Rear Wheel Axle Shims Kit for



APL-AX-139 2515 EX

Rear Wheel Axle Shims Kit for



APL-AX-140 1612/2515 EX

Rear Wheel Axle Shims Kit for



APL-AX-141 407

Anti Roll Bar Kit with Hardware



APL-AX-142 709

Anti Roll Bar Kit with Hardware



APL-AX-143 407

Anti Roll Bar Kit



APL-AX-144 / 709

Anti Roll Bar Kit



APL-AX-145 407 N-M

Anti Roll Bar Kit



APL-AX-146 407 TURBO/EX

Anti Roll Bar Kit



APL-AX-147 1109 MARCOPOLLO

Anti Roll Bar Kit



APL-AX-148 709 TURBO

Anti Roll Bar Kit



APL-AX-149 1109 BS III

Anti Roll Bar Kit



APL-AX-150 1109 EX

Anti Roll Bar Kit



APL-AX-151 1109 BS IV

Anti Roll Bar Kit



APL-AX-152 TATA BUS

Weveller Rubber Front



APL-AX-153 1516/2416

Anti Roll Bar Kit



APL-AX-154 2516/2518

Anti Roll Bar Kit



APL-AX-155 3118

Anti Roll Bar Kit



APL-AX-156 TATA BUS

Weveller Rubber Rear



APL-AX-157 407

Anti Roll Bar Bracket



APL-AX-158 709

Anti Roll Bar Bracket



APL-AX-159 407 TURBO

Anti Roll Bar Bracket



APL-AX-160 1109 MARCOPOLLO

Anti Roll Bar Bracket



APL-PS-101 1510/1612

Centre Joint Bracket (Spicer)



APL-PS-102 4018 EX

Centre Joint Bracket (Spicer)



APL-PS-103 2515 EX

Centre Joint Bracket (Modified)



APL-PS-104 3118

Centre Joint Bracket (Modified)



APL-PS-105 3118

Centre Joint Bracket (Spicer)



APL-PS-106 3118

Centre Joint Bracket (Spicer)



APL-PS-107 3118

Centre Joint Bracket (RSB)



APL-PS-108 3118

Center Joint Bracket (RSB 590/620)



APL-PS-109 3718/3723

Centre Joint Bracket (Spicer)



APL-PS-110 909 EX

Centre Joint Bracket (Spicer)



APL-PS-111 407 TURBO

Centre Joint Bracket (Spicer)



APL-PS-112 LPK 2516

Centre Bearing Cup (88509)



APL-PS-113 2516/2518

Front Teeth Nut (SPL 90)



APL-PS-114 TATA/AL. 3118/4018/AMW

Front Teeth Nut with Washer (SPL 1710)



APL-PS-115 AL. ECOMET/EICHER 20.16

Front Teeth Nut (SPL 1550)



APL-PS-116 LEYLAND 3718

Front Teeth Nut (MSL 2040)



APL-PS-117 2416

Centre Bearing Cup (6211)



APL-PS-118 2518

Centre Bearing Cup (88511)



APL-PS-119 407 TURBO

Centre Bearing Cup (88507)



APL-PS-120 / 709/1109

Centre Bearing Cup (88508)



APL-PS-121

3718/3723

Front Teeth Lock Kit (SPL 2055)



APL-PS-122

2518/3118

Front Teeth Lock Kit (RSB 590)



5 KITS

APL-AP-101

1612

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-102

T.C.

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-103

2515 EX/4018

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-104

1613 TURBO

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-105

LEYLAND CARGO/EICHER

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-106

709/1109

Air Compressor Head Repair Kit (Minor)



5 KITS

APL-AP-107

2515 EX/4018

Air Compressor Head Repair Kit (Minor)



APL-AP-108

2515 EX/4018

Air Compressor Head Repair Kit (Major)



APL-AP-109

3118


Water Cooler Head Repair Kit (Silicon)



APL-AP-110

LEYLAND 4018

Water Cooler Head Repair Kit (Silicon)



APL-AP-111

1616

Air Compressor Head Repair Kit (Silicon)



APL-AP-112

2518

Air Compressor Head Repair Kit (Silicon)



APL-AP-113

PRIMA BS IV

Air Compressor Head Repair Kit



APL-AP-114

1612

Air Compressor Head Repair Kit (Major)



APL-AP-115

T.C.

Air Compressor Head Repair Kit (Major)



APL-AP-116

2515 EX/4018

Air Compressor Head Repair Kit (Major)



APL-AP-117

LEYLAND CARGO/EICHER

Air Compressor Head Repair Kit (Major)



APL-AP-118

709/1109

Air Compressor Head Repair Kit (Major)



APL-AP-119

ALL

Voss Fitting Kit 22 X 1.5 X 6



APL-AP-120

ALL

Voss Fitting Kit 16 X 1.5 X 6



APL-AP-121 ALL

Voss Fitting Kit 22 X 1.5 X 6 'L' Type



APL-AP-122 ALL

Voss Fitting Kit 16 X 1.5 X 6 'L' Type



APL-AP-123 ALL

Voss Fitting Kit 16 X 1.5 X 8



APL-AP-124 ALL

Voss Fitting Kit 22 X 1.5 X 8 'L' Type



APL-AP-125 ALL

Voss Fitting Kit 16 X 1.5 X 8 'L' Type



APL-AP-126 ALL

Voss Fitting Kit 22 X 1.5 X 10



APL-AP-127 ALL

Voss Fitting Kit 16 X 1.5 X 10



APL-AP-128 ALL

Voss Fitting Kit 22 X 1.5 X 10 'L' Type



APL-AP-129 ALL

Voss Fitting Kit 16 X 1.5 X 10 'L' Type



APL-AP-130 ALL

Voss Fitting Kit 22 X 1.5 X 12



APL-AP-131 ALL

Voss Fitting Kit 16 X 1.5 X 12



APL-AP-132 ALL

Voss Fitting Kit 22 X 1.5 X 12 'L' Type



APL-AP-133 ALL

Voss Fitting Kit 16 X 1.5 X 12 'L' Type



APL-AP-134 ALL

Voss Fitting Kit 22 X 1.5 X 15



APL-AP-135 ALL

Voss Fitting Kit 16 X 1.5 X 15



APL-AP-136 ALL

Voss Fitting Kit 22 X 1.5 X 15 'L' Type



APL-AP-137 ALL

Voss Fitting Kit 16 X 1.5 X 15 'L' Type



10 PCS

APL-AP-138 1612

Air Pipe Union 12X 12 mm



10 PCS

APL-AP-139 1612

Air Pipe Union 12X 16 mm



10 PCS

APL-AP-140 1612

Air Pipe Union 12 X 18 mm



10 PCS

APL-AP-141

1612

Air Pipe Union 12 X 22 mm



10 PCS

APL-AP-142

1612

Air Pipe Union 14 X 14 mm



10 PCS

APL-AP-143

1612

Air Pipe Union 14 X 16 mm



10 PCS

APL-AP-144

1612

Air Pipe Union 14 X 18 mm



10 PCS

APL-AP-145

1612

Air Pipe Union 14 X 22 mm



10 PCS

APL-AP-146

1612

Air Pipe Union 16 X 16 mm



10 PCS

APL-AP-147

1612

Air Pipe Union 16 X 18 mm



10 PCS

APL-AP-148

1612

Air Pipe Union 16 X 22 mm



10 PCS

APL-AP-149

1612

Air Pipe Union 18 X 18 mm



10 PCS

APL-AP-150

1612

Air Pipe Union 18 X 22 mm



10 PCS

APL-AP-151

1612

Air Pipe Union 20 X 22 mm



10 PCS

APL-AP-152

1612

Air Pipe Union 22 X 22 mm



6 PCS

APL-AP-153

1612

Air Pipe Union 22 X 26 mm



6 PCS

APL-AP-154

1612

Air Pipe Union 20 X 20 mm




6 PCS

APL-AP-155

1612

Air Pipe Union 22 X 24 mm



6 PCS

APL-AP-156

1612

Air Pipe Union 24 X 24 mm




6 PCS

APL-AP-157

1612

Air Pipe Union 26 X 26 mm



6 PCS

APL-AP-158

1612

Air Pipe Union 12 X 12 mm (Long)



6 PCS

APL-AP-159

1612

Air Pipe Union 18 X 18 mm (Long)



6 PCS

APL-AP-160

1612

Air Pipe Union 22 X 22 mm (Long)



APL-AP-161 UNIVERSAL
Voss Fitting Kit (Thread) 22 X 1.5 X 12



APL-AP-162 UNIVERSAL
Voss Fitting Kit (Thread) 22 X 1.5 X 18



APL-AP-163 UNIVERSAL
Voss Fitting Kit (Thread) 16 X 1.5 X 12



APL-AP-164 UNIVERSAL
Voss Fitting Kit (Thread) 16 X 1.5 X 18



APL-AP-165 ALL
Adopter with 'O' Ring 16 X 22 mm



APL-AP-166 ALL
Adopter with 'O' Ring 18 X 22 mm



APL-AP-167 ALL
Adopter with 'O' Ring 26 X 26 mm



APL-AP-168 1612
Elbow 18 X 18 mm



APL-AP-169 T.C./709/1109
Elbow 22 X 22 mm for A. C. Head



APL-AP-170 1612
Elbow 18 X 22 mm



APL-AP-171 1612
Elbow 26 X 26 mm



APL-AP-172 2515 EX
Elbow 26 X 22 mm for A. C. Head



APL-AP-173 1612
Elbow 12 X 12 mm



APL-AP-174 1612
Elbow 12 X 22mm



APL-AP-175 1612
Elbow 12 X 18 mm



APL-AP-176 1612
Air Pipe Tee 3 Way 12 X 12 X 12mm



APL-AP-177 1612
Air Pipe Tee 3 Way 16 X 16 X 16 mm



APL-AP-178 1612
Air Pipe Tee 3 Way 18 X 18 X 18 mm



APL-AP-179 1612
Air Pipe Tee 3 Way 18 X 22 X 22mm



APL-AP-180 1612
Air Pipe Tee 3 Way 22 X 22 X 22mm



4 PCS

APL-AP-181

1612

Air Pipe Tee 3 Way 18 X 18 X 22 mm



4 PCS

APL-AP-182

1612

Air Pipe Tee 3 Way 26 X 26 X 26 mm



APL-AP-183

1612

Air Tank Drain Valve Brass with Washer



10 KITS

APL-AP-184

1612

Ferrule Kit 06 mm (14 No.)



10 KITS

APL-AP-185

1612

Ferrule Kit 08 mm (17 No.)



10 KITS

APL-AP-186

1612

Ferrule Kit 10mm (19 No.)




10 KITS

APL-AP-187

1612

Ferrule Kit 12 mm (22 No.)



6 KITS

APL-AP-188

1612

Ferrule Kit 15 mm (27 No.)




6 KITS

APL-AP-189

4018

Ferrule Kit 18 mm (32 No.)



6 KITS

APL-AP-190

1612

Ferrule Kit 06 mm with Tee (14 No.)



6 KITS

APL-AP-191

1612

Ferrule Kit 08 mm with Tee (17 No.)




6 KITS

APL-AP-192

1612

Ferrule Kit 10 mm with Tee (19 No.)



6 KITS

APL-AP-193

1612

Ferrule Kit 12mm with Tee (22 No.)



6 KITS

APL-AP-194

1612

Ferrule Kit 15 mm with Tee (27 No.)



6 KITS

APL-AP-195

4018

Ferrule Kit 18 mm with Tee (32 No.)



10 PCS

APL-FU-101

1210 SE

Air Breather Big



APL-FU-102

BOSCH

Pump Switch 24V



APL-FU-103

BOSCH

Pump Switch 12 V



APL-FU-104

CAV

Pump Switch 12V



10 PCS

APL-FU-105

ALL

Sealing Bolt for Diesel Tank



APL-FU-106

T.C.

Diesel Filter Plate Top (10 mm)



APL-FU-107

T.C.

Diesel Filter Plate Top (12 mm)



APL-FU-108

T.C.

Diesel Filter Plate Bottom




10 PCS

APL-FU-109

ALL

Pre-Filter Nylon Strainer (Glass Filter)




10 KITS

APL-FU-110

/ ALL

Feed Pump Valve & Spring Kit of 4 Pcs.




10 KITS

APL-FU-111

ALL

Feed Pump Repair Kit



10 KITS

APL-FU-112

/ ALL

Hand Primer Repair Kit



10 PCS

APL-FU-113

ALL

Pre-Filter Glass (Aluminium)



APL-EL-101 1613 T.C.

Gear Lever Boot (Lip type)



APL-EL-102 4018 EX

Gear Lever Boot (Zip type)



APL-EL-103 / 1613 T.C.

Gear Lever Boot



APL-EL-104 4018 EX

Gear Lever Boot



5 PCS

APL-EL-105 2515 EX

Diesel Filter Switch



5 PCS

APL-EL-106 4018 EX

Diesel Filter Switch



APL-EL-107 4018/1109 BS IV

Diesel Filter Switch



APL-EL-108 1612/407

Gear Knob (PU)



APL-EL-109 1612/407

Gear Knob (Plastic)



APL-EL-110 1613 TURBO

Gear Knob 6 Gear



APL-EL-111 2515 EX

Gear Knob 7 Gear



APL-EL-112 2518/3718

Gear Knob 9 Gear



APL-EL-113 PRIMA 2523

Gear Knob (Gear Shift Cable)



APL-EL-114 PRIMA 4923

Gear Knob (Gear Shift Cable)



APL-EL-115 912/1112 BS IV

Gear Knob (Gear Shift Cable)



APL-EL-116 1613

Alternator Bracket



APL-EL-117 1613 TURBO

Alternator Bracket



APL-EL-118 1613 BS III

Alternator Bracket



APL-EL-119 909/1109 BS IV

Alternator Bracket



APL-EL-120 909

Alternator Bracket



APL-EL-121 1109 BS IV

Alternator Bracket



APL-EL-122 1109

Alternator Bracket



APL-EL-123 / 1109/207 DI

Alternator Bracket



APL-EL-124 407 TURBO

Alternator Bracket



APL-EL-125 407 TURBO

Alternator Bracket



APL-EL-126 T.C.

Alternator Bracket



APL-EL-127 T.C.

Alternator Bracket



APL-EL-128 2515/4018

Gear Lever Sleeve



APL-DR-101 / 407/2515
Door Lock Assembly with Fitting Kit



APL-DR-102 407/2515
Door Lock Assembly with Fitting Kit



APL-DR-103 / 709 LPT/SUM0
Door Lock Assembly (Right)



APL-DR-104 709 LPT/SUM0
Door Lock Assembly (Left)



APL-DR-105 407/709/2515
Door Winder Assembly (Right)



APL-DR-106 / 407/709/2515
Door Winder Assembly (Left)



APL-DR-107 407 TURBO
Door Winder Assembly (Right)



APL-DR-108 407 TURBO
Door Winder Assembly (Left)



APL-DR-109 709 LPT
Door Winder Assembly (Right)



APL-DR-110 709 LPT
Door Winder Assembly (Left)



APL-DR-111 407/709 TURBO
Door Winder Assembly (Right)



APL-DR-112 407/709 TURBO
Door Winder Assembly (Left)



APL-DR-113 / LEYLAND CARGO
Door Lock Assembly (Right)



APL-DR-114 LEYLAND CARGO
Door Lock Assembly (Left)



APL-DR-115 LEYLAND CARGO
Door Winder Assembly (Right)



APL-DR-116 LEYLAND CARGO
Door Winder Assembly (Left)



APL-DR-117 407/709 SFC
Door Lock Spring



APL-DR-118 EICHER 10.80/11.10
Door Winder Assembly (Right)



APL-DR-119 EICHER 10.80/11.10
Door Winder Assembly (Left)



APL-DR-120 407/709/2515
Door Locking Handle



APL-DR-121 407/709/2515
Door Non Locking Handle



APL-DR-122 LPS 4018
Grab Handle (White) with Kit



APL-DR-123 LPS 4018
Grab Handle (Chrome) with Kit



APL-DR-124 407/709 LPT
Door Locking Handle (Right)



APL-DR-125 407/709 LPT
Door Locking Handle (Left)



APL-DR-126 407/J-540
Regulator Glass Handle Set of 2 Pcs.



APL-DR-127 407/709 TURBO
Regulator Glass Handle Set of 2 Pcs.



APL-DR-128 407/2515
R.C. Handle Assembly (RH) Set of 2 Pcs.



APL-DR-129 407/2515
R.C. Handle Assembly (LH) Set of 2 Pcs.



APL-DR-130 SFC 407/709
R.C. Handle Assembly (RH) Set of 2 Pcs.



APL-DR-131 SFC 407/709
R.C. Handle Assembly (LH) Set of 2 Pcs.



APL-DR-132 709/SUM0
R.C. Handle Assembly Set of 2 Pcs.



APL-DR-133 1510/1612 L.P. 6 PCS
Grill Knob



APL-DR-134 1510/1612 L.P. 6 PCS
Grill Knob Lock



APL-DR-135 1510/1612 L.P.
Grill Knob (Backlite) with Lock



APL-DR-136 407/709
Glove Box Lock Assembly with Key



APL-DR-137 / 407/709
Quarter Glass Lock Assembly Set of 2 Pcs



APL-DR-138 DUMPER /HYWA
Door Locking Handle



APL-DR-139 407 50 PCS
Door Hinges Bush (Nylon)



APL-DR-140 / LPK 2516/2518
Bonnet Stopper



APL-DR-141 / LPK 2516/2518

Door Hinge Set Of 2 Pcs.



APL-DR-142 709

Door Hinge Set of 4 Pcs. (Spring Type)



APL-DR-143 1109

Door Hinge Set of 4 Pcs.



APL-DR-144 407/709 SFC

Assembly Bonnet Hinge (Right)



APL-DR-145 407/709 SFC

Assembly Bonnet Hinge (Left)



APL-DR-146 407/709 SFC

Door Lock Catcher



APL-DR-147 709 LPT

Striker Plate



APL-DR-148 407/709 SFC

Bonnet Lock Assembly Lower



APL-DR-149 407/709 SFC

Bonnet Lock Assembly Centre



APL-DR-150 709 LPT

Bonnet Spring Upper



APL-DR-151 / 709 LPT

Bonnet Hook Lower



APL-DR-152 / 407/709 SFC

Door Glass Holder Patty with Fitting Kit



APL-DR-153 407/709 SFC

Assembly Handle



APL-DR-154 407 TURBO

Door Glass Holder Patty Assembly



APL-DR-155 1510/1612

Engine Hood Clip Set of 2 Pcs.



APL-DR-156 407/709 SFC

Door Striker Plate with Pin & Screw



APL-DR-157 / 407/709 SFC

Door Striker Plate with Pin & Screw



APL-DR-158 407/709 SFC

Striker Bolt with Nut (10mm)



APL-DR-159 407 TURBO

Striker Bolt with Nut (8mm)



APL-FS-101 1612
Cylinder Head Stud with Nut




APL-FS-102 1612
Cylinder Head Hex Nut



APL-FS-103 / 1613 TURBO
Main Bearing Cap Bolt



APL-FS-104 1613 TURBO
Cylinder Head Bolt



APL-FS-105 T.C.
Cylinder Head Bolt (M12 X 70)



APL-FS-106 T.C.
Cylinder Head Bolt (M12 X 110)



APL-FS-107 T.C.
Cylinder Head Bolt (M12 X 120)




APL-FS-108 T.C.
Cylinder Head Bolt (M12 X 180)




APL-FS-109 BS III
Cylinder Head Bolt




APL-FS-110 PRIMA
Cylinder Head Bolt




APL-FS-111 407/709
Cylinder Head Bolt



APL-FS-112 T.C.
Fly Wheel Housing Bolt




APL-FS-113 1612
Fly Wheel Bolt



APL-FS-114 BS II
Fly Wheel Bolt




APL-FS-115 / BS III
Fly Wheel Bolt



APL-FS-116 T.C.
Clutch Cover Assembly Bolt



APL-FS-117 1612
Fuel Pump Stud with Nut




APL-FS-118 T.C.
Fuel Pump Stud with Nut



APL-FS-119 / T.C.
Turbo Charger Stud with Nut



APL-FS-120 T.C.
Air Compressor Stud with Nut



25 PCS

APL-FS-121

1612

Stud with Nut (M8 X 35)



25 PCS

APL-FS-122

1612

Stud with Nut (M8 X 40)



25 PCS

APL-FS-123

1612

Stud with Nut (M8 X 50)



25 PCS

APL-FS-124

1612

Stud with Nut (M8 X 60)



10 PCS

APL-FS-125

1613

Connecting Rod Bolt



10 PCS

APL-FS-126

407

Connecting Rod Bolt



10 PCS

APL-FS-127

/ BS II

Connecting Rod Bolt




10 PCS

APL-FS-128

BS III

Connecting Rod Bolt



50 PCS

APL-FS-129

1612

Chamber Stud with Nut



50 PCS

APL-FS-130

BS III

Chamber Screw



5 PCS

APL-FS-131

T.C.

Main Bearing Cap Bolt




10 PCS

APL-FS-132

T.C.

Cylinder Block Bolt



10 PCS

APL-FS-133

T.C.

Starter Bolt



10 PCS

APL-FS-134

T.C.

Starter Bolt (Pump)



10 PCS

APL-FS-135

T.C.

Air Compressor Bolt (Big)



10 PCS

APL-FS-136

T.C.

Air Compressor Bolt (Small)



10 PCS

APL-FS-137

T.C.

Weight Bolt (Small)



10 PCS

APL-FS-138

T.C.

Weight Bolt (Medium)



10 PCS

APL-FS-139

T.C.

Weight Bolt (Big)



10 PCS

APL-FS-140

1613 TURBO

Timing Bolt




10 PCS

APL-FS-141

1612

Rocker Arm Bolt




50 PCS

APL-FS-142

T.C. I

Cam Follower Cover Screw (M8 X 16)




50 PCS

APL-FS-143

/ T.C.

Viscous Fan Screw



50 PCS

APL-FS-144

T.C.

Water Pump Screw (M8 X 22)



10 PCS

APL-FS-145

407 TURBO

Axle Stud Std. Size



10 PCS

APL-FS-146

709 TURBO

Axle Stud Std. Size




10 PCS

APL-FS-147

2515/2518

Brake Carrier Bolt




25 PCS

APL-FS-148

6. 750

Clutch Cover Assembly Bolt




50 PCS

APL-FS-149

T.C.

Timing Cover Screw (M8 X 16)



50 PCS

APL-FS-150

T.C.

Valve Cover Screw (M8 X 22)



50 PCS

APL-FS-151

T.C.

Manifold Intake Cover Screw (M8 X 25)




50 PCS

APL-FS-152

/ T.C.

Valve Cover Bolt (M8 X 35)




25 PCS

APL-FS-153

T.C.

Fan Support Bolt (M8 X 40)



25 PCS

APL-FS-154

T.C.

Timing Housing Gear Screw (M8 X 50)



25 PCS

APL-FS-155

T.C.

Rocker Lever Support Bolt (M8 X 75)




10 PCS

APL-FS-156

T.C.

Air Intake Connection Screw (M8 X 80)




25 PCS

APL-FS-157

T.C.

Fan Pulley Bolt (M10 X 20)




25 PCS

APL-FS-158

T.C.

Air Compressor Bolt (M10 X 25)




25 PCS

APL-FS-159

T.C.

Exhaust Manifold Bolt (M10 X 65)




10 PCS

APL-FS-160

T.C.

Exhaust Manifold Bolt (M10 X 70)




10 PCS

APL-FS-161

T.C.

Belt Tensioner Bolt (M10 X 72)



10 PCS

APL-FS-162

T.C.

Water Inlet Bolt (M10 X 75)



10 PCS

APL-FS-163

T.C.

Damper Vibration Bolt (M12 X 36)



APL-FS-164

3118/3723

Axle Lift Bolt (M24 X 150)



APL-FS-165

3118/3723

Axle Lift Bolt (M24 X 190)



APL-FS-166

3118/3723

Axle Lift Bolt (M24 X 200)



APL-FS-167

3118/3723

Axle Lift Bolt (M24 X 210)



APL-FS-168

3118/3723

Axle Lift Bolt (M24 X 220)



APL-FS-169

3118/3723

Axle Lift Bolt (M27 X 190)



APL-FS-170

3118/3723

Axle Lift Bolt (M27 X 200)



APL-FS-171

3118/3723

Axle Lift Bolt (M27 X 210)



APL-FS-172

3118/3723

Axle Lift Bolt (M27 X 220)




APL-CB-101 407 TURBO

Accelerator Cable (70-62)



APL-CB-102 407 LPT

Accelerator Cable (73-69)



APL-CB-103 410 EX

Accelerator Cable (77-71)



APL-CB-104 407 BUS

Accelerator Cable (125-113)



APL-CB-105 407/709 L.P./LPT

Accelerator Cable (81-77)



APL-CB-106 709/1109 L.P.

Accelerator Cable (63-58)



APL-CB-107 609/709

Accelerator Cable (69-58)



APL-CB-108 1109 MODIFIED

Accelerator Cable (72-58)



APL-CB-109 709/909/1109 LPT

Accelerator Cable (76-65)



APL-CB-110 909/1109

Accelerator Cable (87-82)



APL-CB-111 1109 BS III

Accelerator Cable (89-82)



APL-CB-112 1612 T.C.

Accelerator Cable (96-79)



APL-CB-113 2515 EX/BS II

Accelerator Cable (102-96)



APL-CB-114 3015 EX

Accelerator Cable (109-99)



APL-CB-115 1613 TURBO

Accelerator Cable (97-92)



APL-CB-116 LPT 2515

Accelerator Cable (112-97)(Cowl Cabin)



APL-CB-117 410 EX

Accelerator Cable (119-115)



APL-CB-118 407 TURBO

Accelerator Cable (55-50)



APL-CB-119 2518/3118

Accelerator Cable (128-123)



APL-CB-120 3118 TC/BS III

Accelerator Cable (27-22)



APL-CB-121 407 TURBO
Accelerator Cable (99-95)(Casting End)



APL-CB-122 407 SFC BS II
Accelerator Cable (63-57)(Casting End)



APL-CB-123 1109 TURBO
Accelerator Cable (82-75)(Casting End)



APL-CB-124 909/1109 EURO III
Accelerator Cable (87-82)(Casting End)



APL-CB-125 2515 EX BS III
Accelerator Cable (102-95)(Casting End)



APL-CB-126 2518/3118
Accelerator Cable (146-142)(Casting End)



APL-CB-127 LPK 2518 T.C.
Accelerator Cable (123-116)



APL-CB-128 3723 LPT
Accelerator Cable (132-125)



APL-CB-129 LPK 2518 T.C.
Accelerator Cable (Speed Governor)



APL-CB-130 LPK2518/4018/SIGNA
Accelerator Cable (Speed Governor)



APL-CB-131 407/709 SFC
Bonnet Cable



APL-CB-132 407/709 LPT
Bonnet Cable



APL-CB-133 AMW
Accelerator Cable



APL-CB-134 709/207 DI
Stop Cable (75-68)



APL-CB-135 909/1109
Stop Cable (105-88)



APL-CB-136 709
Stop Cable



APL-CB-137 1109
Stop Cable



APL-CB-138 T.C.
Stop Cable (94-87)



APL-CB-139 T.C.
Stop Cable (100-92)



APL-CB-140 3118/4018
Stop Cable (161-155)



APL-MS-101 407/1510

Alternator Adjuster Assembly (10 mm)



APL-MS-102 407 LATEST

Alternator Adjuster Assembly (12 mm)



APL-MS-103 1612

Alternator Adjuster Assembly -



APL-MS-104 1612 LATEST

Alternator Adjuster Assembly -



APL-MS-105 1510 BUS

Alternator Adjuster Assembly (12 mm)



APL-MS-106 709/1109

Alternator Adjuster Assembly



APL-MS-107 2518/3118

Alternator Adjuster Assembly-



APL-MS-108 909/1109 BS IV

Assembly Clamp Rod (Alternator)



APL-MS-109 909/1109 BS IV

Assembly Clamp Rod (Power Steering)



APL-MS-110 909/1109 BS IV

Assembly Clamp Rod (Power Steering)



APL-MS-111 / 1612

Alternator Adjusting Bolt with Spring



APL-MS-112 1612

Mesh (Jhally) for Suction Tube



APL-MS-113 LPK 2516/2518

Assembly Shift Cylinder



APL-MS-114 LPK 2516/AMW

Assembly Shift Cylinder Inside



APL-MS-115 1612/92 M

Centre Joint Bracket



APL-MS-116 2416

Centre Joint Bracket



APL-MS-117 1612

Fuel Tank Cap with Lock



APL-MS-118 1612

Fuel Tank Cap Lock



APL-MS-119 1612

Fuel Tank Cap Lock without Clip



APL-MS-120 1612

Stepney Gear Lock Kit



5 PCS

APL-MS-121

2416

Centre Joint Bracket Clamp



5 PCS

APL-MS-122

3118

Centre Joint Bracket Clamp (Spicer)



5 PCS

APL-MS-123

3118

Centre Joint Bracket Clamp (RSB)



APL-MS-124

1613/2515

Battery Clamp Rod Set



APL-MS-125

2515 EX

Cabin Mounting Kit (M12 X 110)



APL-MS-126

LPS4018

Cabin Mounting Kit (M12X125)



APL-MS-127

2515 EX

Cabin Mounting Rubber



APL-MS-128

2515 EX

Cabin Mounting Rubber Apple



10 PCS

APL-MS-129

1210 SE

Stepney Cable



10 PCS

APL-MS-130

1210 SE

Stepney Cable (Gold)



APL-MS-131

T.C.

Stepney Cable



APL-MS-132

LEYLAND BS III

Stepney Cable



APL-MS-133

2515/1613/3015 LPK

Hydraulic Cylinder Kit (Tilt Cabin)



APL-MS-134

2515 EX

Cabin Mounting



APL-MS-135

2515 EX

Manual Valve Control Assembly



APL-MS-136

407/608/709

Suction Tube Assembly



APL-MS-137

1210 SE

Suction Tube Assembly 165 Litres



APL-MS-138

1613 T.C.

Suction Tube Assembly 165 Litres



APL-MS-139

1613 T.C.

Suction Tube Assembly 350 Litres



APL-MS-140

2518/3118

Suction Tube Assembly 400 Litres



APL-MS-141 LPS 3516 EX

Cabin Mounting Bracket Set (RH/LH)



APL-MS-142 LPS 4018 EX

Cabin Mounting Bracket Set (RH/LH)



APL-MS-143 / 407/709

Cabin Mounting Bracket



APL-MS-144 407

Diesel Filter Bracket



APL-MS-145

Jack Kit (Rubber)



APL-MS-146

Jack Kit (PVC)



APL-MS-147

Jack Kit (Teflon)



APL-MS-148

Jack Kit (Canvas)



APL-MS-149

Jack Kit (PU)



APL-MS-150

Cabin Plate



APL-MS-151

Cabin Hook (Short)



APL-MS-152

Cabin Hook (Long)



APL-MS-153

(165 Ltr)



APL-MS-154

(350 Ltr)



APL-MS-155

(400 Ltr)



APL-MS-156

Air Tank Strap



APL-MS-157

Fuel Tank Strap



APL-MS-158

Air Cleaner Strap (L)
















APL-MS-159

Air Cleaner Strap



APL-MS-160 38"



Ref. No.	Apel Code	Description	Pg
A001	APL-EN-117	Cylinder Head Seating Washer	1
A003	APL-EN-118	Crank Spacer (Cut)	1
A004	APL-EN-225	Engine Valve Collet Set of 24 Pcs.	7
A006	APL-EN-119	Fly Wheel Lock Plate Set of 4 Pcs.	1
A007	APL-EN-221	Screw with Nut for Rocker Lever	7
A010	APL-EN-369	Cam Cup (Aluminium) (60 mm)	14
A019	APL-EN-181	Air Cleaner Adjusting Bolt with Wing Nut	5
A020	APL-EN-133	Nozzle Washer Set of 18 Pcs.	2
A022	APL-EN-368	Plug Expansions for Cylinder Block	14
A024	APL-EN-129	Temperature Sender Unit (M14 X1.5)	2
A025	APL-EN-296	Oil Pump Strainer	10
A026	APL-EN-297	Oil Pump Strainer	10
A027	APL-EN-298	Oil Pump Strainer	10
A031	APL-EN-229	Valve Tappet Set of 12 Pcs.	7
A034	APL-EN-370	Cylinder Block Plug (60mm)	14
A036	APL-EN-206	Thermostat Assembly (Plastic)	6
A037	APL-EN-205	Thermostat Assembly (Plastic)	6
A038	APL-EN-201	Thermostat Assembly (Brass)	6
A039	APL-EN-125	Oil Filler Assembly	2
A040	APL-EN-202	Thermostat Assembly (Brass)	6
A050	APL-EN-107	Coolant Tank Cap	1
A051	APL-EN-101	Radiator Cap (42 Dia)	1
A052	APL-EN-102	Radiator Cap (Double Seal) (42 Dia)	1
A053	APL-EN-103	Radiator Cap (Stainless Steel) (42 Dia)	1
A054	APL-EN-317	Exhaust Manifold Gasket Set of 2 Pcs.	11
A055	APL-EN-108	Coolant Tank Cap	1
A056	APL-EN-112	D. E. F. Tank Cap	1
A059	APL-EN-197	Radiator Dumble	5
A061	APL-EN-198	Radiator Patti Set of 4 Pcs. (Black)	5
A062	APL-EN-199	Radiator Bracket	5
A063	APL-EN-189	Air Compressor Sleeve (94mm)	5
A064	APL-EN-209	Thermostat Assembly with Valve (Brass)	6
A065	APL-EN-210	Thermostat Assembly with Valve (Brass)	6
A066	APL-EN-193	Air Compressor Sleeve Modified (94mm)	5
A070	APL-EN-156	Rotary Pump Bracket	3
A071	APL-EN-233	Valve Rocker Shaft Set Of 2 Pcs.	7
A072	APL-EN-237	Rocker Push Rod	7
A102	APL-EN-113	Timing Oil Plug	1
A103	APL-EN-109	Oil Filler Cap	1
A104	APL-EN-110	Tappet Oil Cap	1
A105	APL-EN-116	Magnetic Drain Bolt for Engine Oil Sump	1
A106	APL-EN-120	Plug Adopter for Engine Oil Sump	1
A109	APL-EN-203	Thermostat Assembly (Brass)	6
A110	APL-EN-257	Assembly Intermediate Pipe	8
A111	APL-EN-258	Assembly Intermediate Pipe	8
A112	APL-EN-207	Thermostat Assembly (Plastic)	6
A113	APL-EN-204	Thermostat Assembly (Brass)	6
A114	APL-EN-301	Gasket for Intermediate Pipe	11
A116	APL-EN-302	Gasket for Intermediate Pipe Big	11
A117	APL-EN-303	Silencer Gasket	11
A118	APL-EN-304	Silencer Gasket (5 Hole)	11
A120	APL-EN-259	Assembly Intermediate Pipe	8
A121	APL-EN-299	Oil Pump Strainer	10
A122	APL-EN-300	Oil Pump Strainer	10
A123	APL-EN-216	Thermostat Assembly (Brass)	6
A124	APL-EN-208	Thermostat Assembly (Plastic)	6
A125	APL-EN-212	Thermostat Assembly (Plastic)	6
A126	APL-EN-385	Power Steering Pulley (497/697 TCIC)	15
A127	APL-EN-386	Crankshaft Pulley (2 Belt)	15
A128	APL-EN-387	Water Pump Pulley (497 TCIC)	15
A129	APL-EN-388	Water Pump Pulley 6 PK	15
A130	APL-EN-389	Water Pump Pulley 6PK (Single Belt)	15
A131	APL-EN-127	Coolant Tank Assembly	2
A132	APL-EN-152	Nozzle Cooling Spray	3
A133	APL-EN-281	Silencer Bellow 2.5" X 6"	10
A134	APL-EN-282	Silencer Bellow 2.5" X 6" with Pipe	10

Ref. No.	Apel Code	Description	Pg
A135	APL-EN-283	Silencer Bellow 3"x 6"	10
A136	APL-EN-284	Silencer Bellow 3" X 6" with Pipe	10
A137	APL-EN-285	Silencer Bellow 2.5"x 6" Interlocking	10
A138	APL-EN-286	Silencer Bellow 2.5"x 6" Interlocking	10
A139	APL-EN-287	Silencer Bellow 3"x 6" Interlocking	10
A140	APL-EN-288	Silencer Bellow 3"x 6" Interlocking	10
A141	APL-EN-319	Exhaust Manifold Gasket	11
A142	APL-EN-320	Exhaust Manifold Gasket	11
A145	APL-EN-160	EGR Cooler & Common Rail Mounting	3
A146	APL-EN-260	Oil Dipstick	8
A147	APL-EN-390	Crankshaft Pulley (Single Belt)	15
A148	APL-EN-391	Power Steering Pulley	15
A149	APL-EN-392	Water Pump Pulley	15
A151	APL-EN-153	Intermediate Flange With Throttle Valve	3
A152	APL-EN-200	Radiator Mouth	5
A153	APL-EN-191	Air Compressor Sleeve (77mm)	5
A154	APL-EN-195	Air Compressor Sleeve Modified (77 mm)	5
A155	APL-EN-176	Engine Mounting Bracket	4
A156	APL-EN-177	Engine Mounting Bracket	4
A161	APL-EN-405	Water Cooling Line	16
A162	APL-EN-406	Water Cooling Line	16
A163	APL-EN-407	Water Cooling Line	16
A164	APL-EN-408	Water Cooling Line	16
A165	APL-EN-409	Water Cooling Line	16
A166	APL-EN-410	Water Cooling Line	16
A167	APL-EN-411	Water Cooling Line	16
A170	APL-EN-412	Water Cooling Line L Type	16
A171	APL-EN-413	Water Cooling Line	16
A172	APL-EN-414	Water Cooling Line	16
A173	APL-EN-415	Water Cooling Line	16
A174	APL-EN-416	Water Cooling Line L Type	16
A175	APL-EN-417	Water Cooling Line	16
A176	APL-EN-418	Water Cooling Line	16
A177	APL-EN-419	Water Cooling Line L Type	16
A178	APL-EN-420	Water Cooling Line L Type	16
A179	APL-EN-421	Water Cooling Line	17
A180	APL-EN-422	Water Cooling Line with Patti	17
A181	APL-EN-157	Manifold Elbow (3715)	3
A182	APL-EN-158	Manifold Elbow (3723)	3
A183	APL-EN-159	Manifold Elbow (3720)	3
A185	APL-EN-323	Hose Clamp (V-Band 64)	12
A186	APL-EN-324	Hose Clamp (V-Band 80.9)	12
A191	APL-EN-211	Thermostat Assembly with Valve (Brass)	6
A202	APL-EN-115	Magnetic Drain Bolt for Engine Oil Sump	1
A203	APL-EN-104	Oil Filler Cap (Plastic) with Ring	1
A204	APL-EN-143	Fan Support Assembly	3
A205	APL-EN-128	Coolant Tank Assembly	2
A206	APL-EN-114	Coolant Tank Cap	1
A207	APL-EN-361	Air Screw for Fuel Pump	14
A208	APL-EN-362	10 mm Air Compressor Pipe Connector	14
A209	APL-EN-363	12 mm Banjo Bolt with Air Screw	14
A210	APL-EN-364	12 mm Banjo Bolt with Check Valve	14
A211	APL-EN-365	08 mm Check Valve	14
A212	APL-EN-222	Screw with Nut for Rocker Lever	7
A214	APL-EN-226	Engine Valve Collet Set of 24 Pcs.	7
A215	APL-EN-182	Plug Expansion for Rocker Lever	5
A217	APL-EN-371	Cylinder Block Plug (58 mm)	14
A218	APL-EN-130	Temperature Sender Unit	2
A219	APL-EN-372	Plug Expansion (60 mm)	14
A220	APL-EN-183	Service Indicator Assembly	5
A221	APL-EN-121	Assembly Timing Breather without Cap	2
A222	APL-EN-122	Assembly Timing Breather with Cap	2
A223	APL-EN-184	Timing Pin (Nylon) with 'O' Ring	5
A224	APL-EN-134	Nozzle Washer Set of 18 Pcs.	2
A228	APL-EN-139	Fuel Strainer Pipe Set (Thin / Thin)	2
A229	APL-EN-140	Fuel Strainer Pipe Set (Thik / Thin)	2

Ref. No.	Apel Code	Description	Pg
A230	APL-EN-349	Plug Expansions Kit for Cylinder Block	13
A231	APL-EN-240	Valve & Compression Spring Set of 24 Pcs	7
A232	APL-EN-366	Dowel Ring (Big)	14
A233	APL-EN-367	Dowel Ring (Small)	14
A234	APL-EN-314	Exhaust Manifold Gasket Set	11
A235	APL-EN-310	Turbo Charger Gasket	11
A236	APL-EN-305	Silencer Gasket	11
A237	APL-EN-313	Valve Cover Gasket with Isolator Noise	11
A238	APL-EN-311	Turbo Charger Gasket	11
A239	APL-EN-145	Timing Shaft & Bearing Kit	3
A240	APL-EN-149	Nozzle Cooling Kit	3
A241	APL-EN-150	Nozzle Cooling Spray	3
A242	APL-EN-151	Boltfor NozzleCoolingSpray	3
A243	APL-EN-194	Air Compressor Sleeve Modified(70mm)	5
A244	APL-EN-186	Valve Seal Set of 12 Pcs.	5
A245	APL-EN-190	Air Compressor Sleeve (70 mm)	5
A246	APL-EN-230	Valve Tappet Set of 12 Pcs.	7
A247	APL-EN-234	Valve Rocker Shaft Set of 6 Pcs.	7
A248	APL-EN-393	Water Pump Pulley	15
A249	APL-EN-293	Silencer Bellow	10
A250	APL-EN-213	Thermostat Valve	6
A251	APL-EN-141	Belt Tensioner Assembly	3
A253	APL-EN-155	Adopter for Turbo Plumbing	3
A254	APL-EN-321	Hose Clamp (V-Band 79) Economy	12
A255	APL-EN-322	Hose Clamp (V-Band 79) S. S.	12
A256	APL-EN-373	Plug Expansion (9.5mm)	14
A257	APL-EN-374	Plug Expansion (18 mm)	14
A258	APL-EN-375	Plug Expansion (21mm)	14
A259	APL-EN-376	Plug Expansion (32 mm)	14
A260	APL-EN-377	Plug Expansion (25 mm)	14
A261	APL-EN-383	Radiator Plug Big	15
A262	APL-EN-384	Radiator Plug Small	15
A263	APL-EN-269	Radiator Pipe Small	9
A264	APL-EN-270	Radiator Pipe Big	9
A265	APL-EN-131	Fuel Strainer Thick - Thin	2
A267	APL-EN-132	Fuel Strainer Thin - Thin	2
A268	APL-EN-306	Silencer Gasket (3 Hole)	11
A269	APL-EN-307	Silencer Gasket (4 Hole)	11
A270	APL-EN-318	Exhaust Manifold Gasket Set of 2 Pcs.	11
A271	APL-EN-308	Silencer Gasket (4 Hole)	11
A272	APL-EN-241	Assembly Intermediate Pipe (0132)	8
A273	APL-EN-146	Timing Shaft (Rotary Pump)	3
A275	APL-EN-147	Timing Shaft Bearing	3
A276	APL-EN-148	Coupling Rubber for Timing Shaft	3
A277	APL-EN-242	Assembly Intermediate Pipe(0115)	8
A278	APL-EN-243	Assembly Intermediate Pipe (0104)	8
A279	APL-EN-161	Viscous Disconnection 6 Hole (Steel)	4
A280	APL-EN-162	Viscous Disconnection 4 Hole (Steel)	4
A281	APL-EN-163	Viscous Disconnection 6 Hole (Steel)	4
A282	APL-EN-164	Viscous Disconnection 4 Hole (Steel)	4
A284	APL-EN-167	Viscous Disconnection 6 Hole (Aluminium)	4
A285	APL-EN-168	Viscous Disconnection 4 Hole (Aluminium)	4
A286	APL-EN-126	Oil Separator Assembly	2
A287	APL-EN-244	Assembly Intermediate Pipe (0102)	8
A288	APL-EN-245	Assembly Intermediate Pipe(0110)	8
A289	APL-EN-246	Assembly Intermediate Pipe (0117)	8
A290	APL-EN-256	Intermediate Pipe Connection	8
A291	APL-EN-247	Assembly Intermediate Pipe (0136)	8
A292	APL-EN-248	Assembly Intermediate Pipe (0138)	8
A293	APL-EN-249	Assembly Intermediate Pipe(0106)	8
A294	APL-EN-250	Assembly Intermediate Pipe (0107)	8
A295	APL-EN-251	Assembly Intermediate Pipe (0125)	8
A296	APL-EN-252	Assembly Intermediate Pipe (0123)	8
A297	APL-EN-253	Assembly Intermediate Pipe (0109)	8
A298	APL-EN-254	Assembly Intermediate Pipe (0117)	8
A299	APL-EN-255	Assembly Intermediate Pipe (0101)	8

Ref. No.	Apel Code	Description	Pg
A301	APL-EN-328	T - Bolt Hose Clamp (28 No.) 2"	12
A302	APL-EN-329	T - Bolt Hose Clamp (34 No.) 2 ¼"	12
A303	APL-EN-330	T - Bolt Hose Clamp (38 No.) 2 ½"	12
A304	APL-EN-331	T - Bolt Hose Clamp (40 No.) 2 ¾"	12
A305	APL-EN-332	T - Bolt Hose Clamp (44 No.) 3"	12
A307	APL-EN-333	T - Bolt Hose Clamp (54 No.) 3"	12
A308	APL-EN-334	T - Bolt Hose Clamp (60 No.) 3 ¼"	12
A309	APL-EN-335	T - Bolt Hose Clamp (66 No.) 3 ½"	12
A311	APL-EN-336	T - Bolt Hose Clamp (72 No.) 3 ½"	12
A313	APL-EN-337	T - Bolt Hose Clamp (76 No.) 3 ¾"	12
A315	APL-EN-338	T - Bolt Hose Clamp (96 No.) 4"	12
A317	APL-EN-339	T - Bolt Hose Clamp (112 No.) 4 ½"	12
A319	APL-EN-340	T - Bolt Hose Clamp (144 No.) 5 ½"	12
A320	APL-EN-171	T - Bolt Hose Clamp (SLTB 64)	4
A321	APL-EN-172	T - Bolt Hose Clamp (SLTB 72)	4
A326	APL-EN-173	T - Bolt Hose Clamp (SLTB 80)	4
A327	APL-EN-174	T - Bolt Hose Clamp (SLTB 84)	4
A331	APL-EN-175	T - Bolt Hose Clamp (SLTB 102)	4
A341	APL-EN-238	Rocker Push Rod	7
A342	APL-EN-224	Rocker Assembly	7
A343	APL-EN-220	Crank Sleeve	6
A344	APL-EN-165	Viscous Disconnection 6 Hole (Aluminium)	4
A345	APL-EN-166	Viscous Disconnection 4 Hole (Aluminium)	4
A346	APL-EN-169	Viscous Disconnection 6 Hole (Steel)	4
A347	APL-EN-170	Viscous Disconnection 4 Hole (Steel)	4
A348	APL-EN-154	Intermediate Flange With Throttle Valve	3
A349	APL-EN-137	Air Cleaner Assembly	2
A350	APL-EN-138	Air Cleaner Assembly Cover	2
A351	APL-EN-187	Valve Seal Set of 24 Pcs.	5
A352	APL-EN-227	Engine Valve Collet Set of 48 Pcs.	7
A353	APL-EN-271	Radiator Pipe	9
A354	APL-EN-214	Thermostat Valve	6
A355	APL-EN-111	Tappet Cap	1
A356	APL-EN-123	Crank Case Breather	2
A357	APL-EN-124	Timing Breather (Sensor)	2
A358	APL-EN-395	Water Pump Pulley	15
A359	APL-EN-315	Exhaust Manifold Gasket Set	11
A360	APL-EN-142	Belt Tensioner Assembly	3
A361	APL-EN-350	Plug Expansion Kit for Cylinder Block	13
A362	APL-EN-351	Plug Expansion Kit for Cylinder Head	13
A364	APL-EN-144	Fan Support Assembly	3
A366	APL-EN-231	Valve Tappet Set of 12 Pcs.	7
A368	APL-EN-196	Air Compressor Head Pipe	5
A370	APL-EN-185	Timing And Main Bearing Oilseal Kit	5
A372	APL-EN-235	Valve Rocker Shaft Set of 2 Pcs.	7
A373	APL-EN-239	Rocker Push Rod	7
A374	APL-EN-352	Cross Head Valve Set	13
A375	APL-EN-356	Injector Clamp Set	13
A376	APL-EN-342	Exhaust Manifold Sleeve	13
A377	APL-EN-192	Oil Pump Assembly	5
A381	APL-EN-223	Screw With Nut For Rocket Lever	7
A382	APL-EN-341	Exhaust Manifold Mounting Kit	13
A384	APL-EN-343	Air Compressor Stud Kit	13
A385	APL-EN-344	Turbo Charger Stud Kit	13
A386	APL-EN-345	Fuel Pump Stud Kit	13
A387	APL-EN-346	Valve Cover Bolt With Isolator	13
A388	APL-EN-347	Injector Flange Head Cap Screw	13
A389	APL-EN-348	Injector Screw (Set of 6 Pcs.)	13
A391	APL-EN-217	Radiator Mounting Kit	6
A392	APL-EN-218	Radiator Mounting Kit (Intercooler)	6
A393	APL-EN-135	Nozzle Washer Set	2
A394	APL-EN-136	Nozzle Washer Set	2
A395	APL-EN-219	Radiator Mounting Kit	6
A399	APL-EN-268	Engine Mounting Arm	9
A454	APL-EN-215	Thermostat Valve	6
A458	APL-EN-316	Exhaust Manifold Gasket Set	11

Ref. No.	Apel Code	Description	Pg
A459	APL-EN-309	Silencer Gasket	11
A460	APL-EN-312	Turbocharger Gasket	11
A469	APL-EN-378	Plug Expansion (27.5mm)	14
A470	APL-EN-188	Valve Seal Set Of 24 Pcs.	5
A473	APL-EN-228	Rocker Assembly	7
A474	APL-EN-236	Valve Rocker Shaft Set of 2 Pcs.	7
A475	APL-EN-232	Valve Tappet Set of 12 Pcs.	7
A501	APL-EN-353	Oil Gauge Pipe Stick (43.5")	13
A502	APL-EN-354	Oil Gauge Pipe Stick (52")	13
A503	APL-EN-355	Oil Gauge Pipe Stick (52.6")	13
A504	APL-EN-357	Oil Gauge Pipe Stick (55")	13
A505	APL-EN-358	Oil Gauge Pipe Stick (59)	13
A506	APL-EN-359	Oil Gauge Pipe Stick (60")	13
A507	APL-EN-360	Oil Gauge Pipe Stick (63")	13
A511	APL-EN-272	Radiator Pipe	9
A512	APL-EN-273	Radiator Pipe	9
A513	APL-EN-274	Radiator Pipe	9
A514	APL-EN-275	Radiator Pipe	9
A516	APL-EN-276	Radiator Pipe	9
A517	APL-EN-277	Radiator Pipe	9
A518	APL-EN-278	Radiator Pipe	9
A521	APL-EN-279	Radiator Pipe	9
A524	APL-EN-280	Radiator Pipe	9
A531	APL-EN-261	Water Cooling Line	9
A532	APL-EN-262	Water Cooling Line	9
A533	APL-EN-263	Water Cooling Line	9
A534	APL-EN-264	Water Cooling Line	9
A535	APL-EN-265	Water Cooling Line	9
A536	APL-EN-266	Water Cooling Line (Sensor)	9
A537	APL-EN-267	Water Cooling Line	9
A541	APL-EN-289	Silencer Bellow 3"X 4"	10
A545	APL-EN-290	Silencer Bellow 4"X6"	10
A551	APL-EN-423	Fan Shroud (B97 TCIC)	17
A552	APL-EN-424	Fan Shroud	17
A571	APL-EN-396	Water Pump Pulley (Casting)	15
A572	APL-EN-394	Water Pump Pulley (Casting)	15
A573	APL-EN-398	Water Pump Pulley (3 Belt)	15
A574	APL-EN-397	Water Pump Pulley (3 Belt)	15
A575	APL-EN-401	Water Pump Pulley 8 PK	16
A576	APL-EN-402	Alternator Pulley 7 PK	16
A577	APL-EN-403	Alternator Pulley (Double Belt)	16
A578	APL-EN-404	Alternator Pulley	16
A579	APL-EN-399	Power Steering Pulley (ZF)	15
A580	APL-EN-400	Power Steering Pulley (Rane)	15
A583	APL-EN-178	Engine Mounting Bracket	4
A584	APL-EN-179	Engine Mounting Bracket	4
A585	APL-EN-180	Engine Mounting Bracket	4
A591	APL-EN-379	Plug Expansions (13mm)	14
A592	APL-EN-380	Plug Expansions (22.6 mm)	14
A593	APL-EN-381	Plug Expansions (26 mm)	15
A594	APL-EN-382	Plug Expansions (38mm)	15
A601	APL-EN-325	Hose Clamp (V-Band 65)	12
A602	APL-EN-326	Hose Clamp (V-Band 80.4)	12
A603	APL-EN-327	Hose Clamp (V-Band 113.7)	12
A611	APL-EN-294	Silencer Bellow	10
A612	APL-EN-295	Silencer Bellow	10
A836	APL-EN-105	Radiator Cap (31 Dia)	1
A837	APL-EN-106	Radiator Cap (Stainless Steel)(31 Dia)	1
A875	APL-EN-291	Silencer Bellow 2 4"X4"	10
A876	APL-EN-292	Silencer Bellow 2 1/2" X 8"	10
B001	APL-GR-101	Gear Box Shims Kit with Cotter Pin	19
B002	APL-GR-102	Gear Box Shims Kit	19
B003	APL-GR-133	Gear Top Cover Doom	20
B004	APL-GR-115	End Piece for Gear Lever Rod	19
B005	APL-GR-105	Synchronizer Kit	19
B008	APL-GR-108	1"Speed Gear Roller Set of 115 Pcs.	19

Ref. No.	Apel Code	Description	Pg
B009	APL-GR-121	Gear Lever Kit	20
B012	APL-GR-157	Shifter LeverJ- Type	21
B013	APL-GR-149	Shifter Lever (Thin Splines)	21
B016	APL-GR-125	Selector Shifter Shaft Kit	20
B017	APL-GR-103	Main Drive Gear Check Nut Set	19
B019	APL-GR-104	Main Shaft Nut	19
B020	APL-GR-128	Dowel Sleeve Set of 2Pcs.	20
B022	APL-GR-305	Top Cover Assembly	29
B023	APL-GR-131	Counter Gear Circlip	20
B025	APL-GR-126	Selector Shifter Shaft Bearing Set of 2 Pcs	20
B026	APL-GR-117	Shifting Shaft Ball & Spring Set of 12 Pcs.	19
B027	APL-GR-127	Selector Shifter Shaft Oil Seal Set of 2 Pcs	20
B028	APL-GR-118	Main Shaft Pin & Spring	19
B030	APL-GR-130	Main Drive Gear Lock	20
B034	APL-GR-132	Snap Ring for 6309N / NU 309N Bearing	20
B035	APL-GR-116	End Piece For Gear Lever Rod	19
B037	APL-GR-129	Main Drive Gear Lock Kit of 2 Pcs.	20
B038	APL-GR-120	Reverse Idler Shaft	19
B043	APL-GR-137	Gear Lever Pin Std.	20
B044	APL-GR-138	Gear Lever Pin 1"O/S.	20
B045	APL-GR-134	Gear Lever Pin Std.	20
B046	APL-GR-135	Gear Lever Pin 1" O/S.	20
B047	APL-GR-136	Gear Lever Pin 2" O/S	20
B051	APL-GR-112	Shifter Guide Plate	19
B054	APL-GR-113	Gear Lever Rubber Bracket	19
B055	APL-GR-122	Gear Lever Kit	20
B056	APL-GR-150	Shifter Lever (Thick Splines)	21
B057	APL-GR-141	Selector Shaft	21
B058	APL-GR-119	Air Breather Assembly (12 mm)	19
B059	APL-GR-114	Gear Lever Rubber Bracket	19
B060	APL-GR-109	Oil Filling Plug for Gear & Differential	19
B062	APL-GR-123	Gear Lever Kit of 5 Pcs.	20
B064	APL-GR-151	Shifter Lever (Top Thin)	21
B066	APL-GR-106	Synchronizer Special Kit	19
B067	APL-GR-124	Gear Lever Cup	20
B068	APL-GR-111	Speedo Gear Set of 2 Pcs.	19
B070	APL-GR-107	Synchronizer Special Kit for Reverse Gear	19
B074	APL-GR-312	End Piece for Assembly Turning Tube	29
B076	APL-GR-317	Gear Lever	29
B077	APL-GR-318	Gear Lever	29
B081	APL-GR-313	Gear Lever with J. Arm	29
B082	APL-GR-314	Gear Lever with J. Arm	29
B091	APL-GR-261	Gear Lever Kit	27
B092	APL-GR-262	Gear Top Cover Kit	27
B093	APL-GR-263	Housing Block	27
B094	APL-GR-264	Gear Lever Rubber Boot Kit	27
B101	APL-GR-161	Gear Box Shims Kit	22
B102	APL-GR-201	Synchronizer Kit	24
B103	APL-GR-203	Synchronizer Kit	24
B106	APL-GR-163	Synchronizer Lock Kit of 5 Pcs.	22
B107	APL-GR-164	Dowel Sleeve Set of 2 Pcs.	22
B108	APL-GR-165	Counter Gear Lock Kit	22
B110	APL-GR-166	Main Shaft Circlip Set of 2 Pcs.	22
B112	APL-GR-169	Main Shaft Nut / Pinion Nut /	22
B113	APL-GR-167	Counter Gear Circlip	22
B114	APL-GR-173	Shifting Shaft Kit (Major)	22
B115	APL-GR-190	Gear Lever Bush (Nylon) with Spacer	23
B116	APL-GR-193	Gear Lever Bush (Nylon)	23
B117	APL-GR-194	Gear Lever Bush (Nylon)	23
B118	APL-GR-189	Gear Lever Plate Set of 8 Pcs.	23
B119	APL-GR-181	Gear Lever Bolt with Nylon Bush	23
B122	APL-GR-139	Gear Lever Pin Std. with Lock	20
B123	APL-GR-140	Gear Lever Pin O/S. with Lock	20
B124	APL-GR-168	Gear Top Cover Mouth with Pin	22
B125	APL-GR-162	Gear Box Overhauling Kit	22
B126	APL-GR-207	Selector Shaft Kit	24

Ref. No.	Apel Code	Description	Pg
B127	APL-GR-208	Gear Top Cover Kit	24
B128	APL-GR-175	Shifting Shaft Kit of 3 Pcs.	22
B129	APL-GR-231	Dowel Sleeve Set of 2 Pcs.	25
B130	APL-GR-176	Reverse Dog Kit	22
B132	APL-GR-170	Main Drive Gear Check Nut Set	22
B133	APL-GR-171	Gear Lever Kit of 5 Pcs.	22
B134	APL-GR-183	Gear Lever Kit of 8 Pcs. (Nylon)	23
B135	APL-GR-182	Gear Lever Bolt with Nylon Bush	23
B136	APL-GR-184	Gear Lever Kit of 8 Pcs. (Nylon)	23
B137	APL-GR-202	Synchronizer Special Kit	24
B138	APL-GR-204	Synchronizer Special Kit	24
B142	APL-GR-340	Reverse Gear Washer Set of 2 Pcs.	30
B144	APL-GR-145	Selector Shaft	21
B145	APL-GR-153	Shifter Lever (Top Thick)	21
B148	APL-GR-213	Gear Lever	24
B151	APL-GR-174	Shifting Shaft Kit (Minor) Set of 3 Pcs.	22
B152	APL-GR-172	Gear Lever Cup	22
B153	APL-GR-210	Air Breather Assembly (10mm)	24
B154	APL-GR-211	Speedo Gear Set of 2 Pcs.	24
B155	APL-GR-212	Speedo Gear Set of 2 Pcs.	24
B156	APL-GR-152	Shifter Lever (Top Thick)	21
B157	APL-GR-191	Assembly Gear Lever	23
B158	APL-GR-192	Assembly Gear Lever	23
B159	APL-GR-195	Gear Bellow	23
B166	APL-GR-185	Gear Lever Bolt with Steel Bush	23
B167	APL-GR-186	Gear Lever Bolt with Steel Bush	23
B168	APL-GR-187	Gear Lever Kit of 8 Pcs. (Steel)	23
B169	APL-GR-188	Gear Lever Kit of 8 Pcs. (Steel)	23
B170	APL-GR-154	Shifter Lever (Top Thin)	21
B171	APL-GR-196	Gear Linkage Stud (6") with Nut	23
B172	APL-GR-197	Gear Linkage Stud (8") with Nut	23
B173	APL-GR-198	Gear Linkage Stud (9") with Nut	23
B174	APL-GR-177	Reverse Idler Shaft	22
B175	APL-GR-178	Reverse Idler Shaft	22
B176	APL-GR-209	Speedo Gear Cover	24
B178	APL-GR-306	Top Cover Assembly	29
B180	APL-GR-199	Gear Linkage Rod (10") with Nut	23
B181	APL-GR-200	Gear Linkage Stud (12) with Nut	23
B185	APL-GR-216	Gear Shift Lever Bracket (Power Steering)	24
B186	APL-GR-217	Gear Shift Lever Bracket (Bush Type)	24
B187	APL-GR-218	Gear Shift Lever Bracket	24
B188	APL-GR-219	Gear Shift Lever Bracket (Big)	24
B189	APL-GR-220	Gear Shift Lever Bracket (Small)	24
B251	APL-GR-328	Selection Lever	30
B252	APL-GR-158	Shifter Lever 'L' Type	21
B253	APL-GR-159	Shifter Lever	21
B254	APL-GR-327	Shifter Finger	30
B255	APL-GR-146	Selector Shaft	21
B256	APL-GR-160	Shifter Lever	21
B257	APL-GR-214	Gear Lever (G.550)	24
B258	APL-GR-215	Gear Lever	24
B263	APL-GR-205	Synchronizer Kit (G.550)	24
B271	APL-GR-253	Synchronizer Cone (1" 2")	26
B272	APL-GR-254	Intermediate Cone (1" 2") Carbon Lining	26
B273	APL-GR-255	Synchronizer Cone (108 Dia)	26
B274	APL-GR-256	Synchronizer Cone (96 Dia)	26
B355	APL-GR-148	Selector Shaft (Cable Shift)	21
B401	APL-GR-221	Gear Box Shims Kit	25
B402	APL-GR-223	Main Shaft Nut	25
B403	APL-GR-241	Synchronizer Kit	26
B405	APL-GR-237	Speedo Gear Cover	25
B406	APL-GR-238	Speedo Gear Cover	25
B409	APL-GR-244	Shifter Fork Brass Pad Set of 2 Pcs.	26
B410	APL-GR-234	Pivot Pin (Top Cover)	25
B413	APL-GR-249	Circlip for 4° Speed	26
B414	APL-GR-250	Circlip for 5° Speed	26

Ref. No.	Apel Code	Description	Pg
B415	APL-GR-245	Main Shaft Circlip Set	26
B417	APL-GR-281	Main Shaft Washer	28
B418	APL-GR-252	Air Breather Assembly (14mm)	26
B419	APL-GR-282	Main Shaft Washer (Collar)	28
B420	APL-GR-283	Main Shaft Washer (4" Gear)	28
B421	APL-GR-284	Main Shaft Spacer (Coupling flange)	28
B423	APL-GR-233	Plug for Shifter Shaft Rear	25
B425	APL-GR-265	Synchronizer Ring (Splines) Big	27
B426	APL-GR-266	Synchronizer Ring (Splines) Small	27
B429	APL-GR-267	Synchronizer Ring (Carbon Line) Big	27
B430	APL-GR-268	Synchronizer Ring (Carbon Line) Small	27
B431	APL-GR-225	Detent Kit	25
B432	APL-GR-226	Detent Kit of 4 Pcs.	25
B433	APL-GR-232	Spiral Pin for Shifter Shaft	25
B435	APL-GR-142	Selector Shaft (Dumper)	21
B436	APL-GR-309	Selector Shifter Shaft Kit (Major)	29
B437	APL-GR-227	Detent Kit of 7 Pcs.	25
B439	APL-GR-310	Gear Top Cover Kit	29
B442	APL-GR-307	Shifter Finger	29
B443	APL-GR-321	Gear Box Retainer	30
B444	APL-GR-280	Speedo Gear Set of 2 Pcs.	27
B445	APL-GR-229	Gear Top Cover Needle Roller Set	25
B446	APL-GR-230	Main Drive Gear Trust Bearing	25
B448	APL-GR-301	Top Cover Assembly (0130)	29
B449	APL-GR-302	Top Cover Assembly (0126)	29
B451	APL-GR-228	Gear Lever Kit	25
B453	APL-GR-322	Gear Front Cover Upper	30
B454	APL-GR-323	Gear Front Cover Lower	30
B455	APL-GR-143	Selector Shaft (Truck)	21
B456	APL-GR-269	Synchronizer Cone (Small)(48 Teeth)	27
B457	APL-GR-270	Synchronizer Cone (Big)(51 Teeth)	27
B458	APL-GR-308	Stop Segment	29
B459	APL-GR-271	Synchronizer Cone (4605)	27
B460	APL-GR-324	Gear Rear Cover Lower	30
B461	APL-GR-272	Synchronizer Ring (4" Speed)(4644)	27
B462	APL-GR-273	Synchronizer Ring (5"Speed)(4645)	27
B463	APL-GR-274	Engaging Gear (5" Speed)(4640)	27
B464	APL-GR-275	Shifter Sleeve 1/2/3"/ (4618)	27
B465	APL-GR-240	Reverse Idler Shaft	25
B466	APL-GR-236	Gear Shifting Yoke	25
B467	APL-GR-297	Gear Fork (5125) 1/2"/3"/4**	28
B468	APL-GR-298	Gear Fork (5127) 5"/6"	28
B469	APL-GR-299	Gear Fork (5113) Reverse	28
B470	APL-GR-300	Gear Fork (5126) 5"/6"	28
B471	APL-GR-293	Shifter Shaft (1" - 2") 7908	28
B472	APL-GR-294	Shifter Shaft (3" - 4") 7910	28
B473	APL-GR-295	Shifter Shaft (5" - 6") 7907	28
B474	APL-GR-296	Shifter Shaft (Reverse) 7909	28
B475	APL-GR-276	Engg. Gear Reverse 32T (4616)	27
B476	APL-GR-277	Engg. Gear 4°/5"/6" (4612)	27
B477	APL-GR-278	Engg. Gear 1°/2* (4615)	27
B478	APL-GR-279	Engg. Gear 3°/4° (4621)	27
B481	APL-GR-315	Gear Lever with J. Arm	29
B482	APL-GR-316	Gear Lever	29
B483	APL-GR-320	Gear Lever	29
B484	APL-GR-319	Gear Lever	29
B489	APL-GR-325	P.T.O. Plate	30
B490	APL-GR-326	P.T.O. Plate	30
B491	APL-GR-351	Gear Shift Lever Bracket	31
B492	APL-GR-352	Gear Shift Lever Bracket	31
B493	APL-GR-353	Gear Shift Lever Bracket (Modified)	31
B494	APL-GR-354	Gear Shift Lever Bracket	31
B495	APL-GR-355	Gear Shift Lever Bracket	31
B496	APL-GR-356	Gear Shift Lever Bracket	31
B501	APL-GR-222	Gear Box Shims Kit	25
B503	APL-GR-242	Synchronizer Kit	26

Ref. No.	Apel Code	Description	Pg
B504	APL-GR-251	Snap Ring (Thick)	26
B505	APL-GR-329	Synchronizer Ring (134 mm)(4656)	30
B506	APL-GR-330	Synchronizer Ring (132 mm)(4655)	30
B509	APL-GR-224	Main Shaft Nut	25
B510	APL-GR-285	Main Shaft Washer (2 Cut)	28
B511	APL-GR-246	Main Shaft Circlip Set	26
B512	APL-GR-331	Assembly Synchronizer Cone	30
B513	APL-GR-333	Inner Cone 1°/2 (Carbon Lining)(4657)	30
B514	APL-GR-334	Intermediate Cone 1°/2°(4639)	30
B515	APL-GR-335	Synchro Ring 1°/2°/3°(4628)	30
B516	APL-GR-336	Shifter Sleeve (4631)	30
B517	APL-GR-337	Synch. Cone 3° Speed (4653)	30
B518	APL-GR-338	Synch. Cone 4° Speed (4654)	30
B519	APL-GR-339	Synch. Cone 5°/6° (4630)	30
B520	APL-GR-286	Main Shaft Washer (4 Cut)	28
B521	APL-GR-303	Top Cover Assembly (0134)	29
B522	APL-GR-248	Shifter Fork Brass Pad Set of 2 Pcs.	26
B524	APL-GR-155	Shifter Lever (Top Thick)	21
B525	APL-GR-144	Selector Shaft	21
B526	APL-GR-156	Shifter Lever (Top Thin)	21
B529	APL-GR-304	Top Cover Assembly (0138)	29
B532	APL-GR-235	Pivot Pin (Top Cover)	25
B536	APL-GR-239	Speedo Gear Cover	25
B552	APL-GR-332	Assembly Synchronizer Cone	30
B571	APL-GR-257	Shifter Shaft (1" - 2") (7914)	26
B572	APL-GR-258	Shifter Shaft (3" - 4") (7915)	26
B573	APL-GR-259	Shifter Shaft (5" - 6") (7916)	26
B574	APL-GR-260	Shifter Shaft (Reverse) (7918)	26
B591	APL-GR-357	Gear Box Bracket Set (Plain) R/L	31
B592	APL-GR-358	Gear Box Bracket Set (Patti) R/L	31
B593	APL-GR-359	Gear Box Bracket Right "H"	31
B594	APL-GR-360	Gear Box Bracket Left "H"	31
B603	APL-GR-243	Synchronizer Kit	26
B615	APL-GR-247	Main Shaft Circlip Set	26
B619	APL-GR-287	Main Shaft Washer (A)	28
B620	APL-GR-288	Main Shaft Washer (B)	28
B621	APL-GR-289	Main Shaft Washer (C)	28
B622	APL-GR-290	Main Shaft Washer (Plain)	28
B623	APL-GR-291	Main Shaft Washer (Collar Type)	28
B624	APL-GR-292	Main Shaft Washer	28
B631	APL-GR-341	Synchronizer Ring (4613)	31
B632	APL-GR-342	Synchronizer Ring (4614)	31
B633	APL-GR-343	Synchronizer Cone (Straight)(4607)	31
B634	APL-GR-344	Synchronizer Cone (26 Splines)(4611)	31
B635	APL-GR-345	Synch. Cone 1°/2° (38-51)(4605)	31
B636	APL-GR-346	Synch. Cone 3°/4° (45-51)(4606)	31
B637	APL-GR-347	Synchro Ring (Drive Shaft) (36 X 51)	31
B639	APL-GR-311	Gear Top Cover Kit	29
B641	APL-GR-348	Sleeve (Range Set) 51 Teeth (4610)	31
B642	APL-GR-349	Shifter Sleeve (Crawler/Rev.) 51T (4612)	31
B643	APL-GR-350	Shifter Sleeve (Crawler/Rev.)	31
B650	APL-GR-147	Selector Shaft	21
B971	APL-GR-179	Gear Lever Kit	22
B972	APL-GR-206	Synchronizer Kit	24
B973	APL-GR-180	Gear Box Repair Kit	22
C003	APL-CL-138	Clutch Pedal Spring	33
C004	APL-CL-167	Clutch Oil Container	35
C005	APL-CL-141	Clutch Patti Assembly Set	34
C006	APL-CL-149	Clutch Patti Race with Lock	34
C008	APL-CL-145	Clutch Patti Set	34
C010	APL-CL-115	Clutch Cylinder Bracket	32
C011	APL-CL-116	Clutch Cylinder Bracket	32
C012	APL-CL-117	Clutch Cylinder Bracket	32
C013	APL-CL-118	Clutch Cylinder Bracket	32
C014	APL-CL-113	Clutch Finger Pin & Bush	32
C018	APL-CL-161	Clutch Pedal Kit (12 mm)	35

Ref. No.	Apel Code	Description	Pg
C019	APL-CL-165	Clutch & Brake Pedal Kit (Major)	35
C021	APL-CL-148	Clutch Cylinder Push Rod Assembly	34
C026	APL-CL-160	Clutch Cylinder Push Rod Assembly	34
C027	APL-CL-150	Clutch Patti Race with Lock	34
C029	APL-CL-125	Clutch Fork Shaft with Bush & Key	33
C030	APL-CL-128	Clutch Fork Shaft Bush & Key Kit	33
C033	APL-CL-101	Clutch Repair Kit (352 Dia) with Bearing	32
C034	APL-CL-102	Pin, Circlip & Bearing Kit (352 Dia)	32
C036	APL-CL-103	Pin, Circlip & Washer Kit (352 Dia)	32
C043	APL-CL-104	Clutch Repair Kit (330 Dia) with Bearing	32
C044	APL-CL-108	Pin, Circlip & Bearing Kit (330 Dia)	32
C052	APL-CL-135	Collector Ring (330 Dia)	33
C053	APL-CL-143	Clutch Patti Assembly Set	34
C054	APL-CL-147	Clutch Patti Set	34
C055	APL-CL-142	Clutch Patti Assembly Set	34
C056	APL-CL-146	Clutch Patti Set	34
C057	APL-CL-121	Clutch Fork Assembly	33
C059	APL-CL-126	Clutch Fork Shaft with Bush & Key	33
C060	APL-CL-127	Clutch Fork Shaft with Bush & Key	33
C061	APL-CL-129	Cross Shaft with Lever (380 Dia)	33
C062	APL-CL-133	Clutch Shaft Lever	33
C063	APL-CL-122	Clutch Fork Assembly	33
C065	APL-CL-130	Cross Shaft With Lever (352 Dia)	33
C066	APL-CL-131	Cross Shaft (352 Dia Organic)	33
C067	APL-CL-137	Cross Shaft Kit (352 Dia)	33
C068	APL-CL-134	Cross Shaft Lever	33
C069	APL-CL-123	Clutch Fork Assembly	33
C070	APL-CL-132	Clutch Fork Setting Kit	33
C073	APL-CL-109	Clutch Lever Bearing (Cage Type)	32
C074	APL-CL-110	Clutch Lever Bearing (Cage Type)	32
C075	APL-CL-111	Clutch Lever Bearing (Roller Type)	32
C076	APL-CL-112	Clutch Lever Bearing (Roller Type)	32
C081	APL-CL-105	Clutch Repair Kit 380 Dia with Bearing	32
C083	APL-CL-136	Collector Ring (380 Dia)	33
C084	APL-CL-107	Pin, Circlip & Washer Kit (380 Dia)	32
C085	APL-CL-106	Pin, Circlip & Bearing Kit (380 Dia)	32
C088	APL-CL-168	Clutch Oil Container	35
C101	APL-CL-144	Clutch Patti Assembly Set	34
C102	APL-CL-162	Clutch Pedal Kit (10 mm)	35
C103	APL-CL-163	Brake Pedal Eccentric Pin Kit	35
C106	APL-CL-151	Clutch Cylinder Push Rod Assembly	34
C108	APL-CL-164	Clutch Pedal Kit (Major)	35
C109	APL-CL-166	Clutch Pedal Kit (Major)	35
C111	APL-CL-152	Clutch Cylinder Yoke	34
C115	APL-CL-114	Clutch and Brake Pedal Spring	32
C133	APL-CL-153	Clutch Thrust Rod Assembly (6")	34
C134	APL-CL-154	Clutch Thrust Rod Assembly (5")	34
C135	APL-CL-155	Clutch Thrust Rod Assembly (4")	34
C136	APL-CL-156	Clutch Thrust Rod Assembly (6¾")	34
C137	APL-CL-157	Clutch Thrust Rod Assembly (6¼")	34
C138	APL-CL-158	Clutch Thrust Rod Assembly (6¾")	34
C139	APL-CL-159	Clutch Thrust Rod Assembly (5")	34
C151	APL-CL-124	Clutch Fork Assembly	33
C152	APL-CL-119	Clutch Cylinder Bracket	32
C153	APL-CL-120	Clutch Cylinder Bracket	32
C171	APL-CL-139	Clutch Pedal Assembly	33
C172	APL-CL-140	Clutch Pedal Assembly	33
D001	APL-BR-163	Brake Cam Bush Set (Front)(Kalyani)	39
D002	APL-BR-164	Brake Cam Bush Set (Rear)(Kalyani)	39
D003	APL-BR-157	Brake Cam Oil Seal Set of 2 Pcs. (TVS)	38
D004	APL-BR-158	Brake Cam Oil Seal Set of 2 Pcs. (Kalyani)	38
D006	APL-BR-115	Brake Oil Container with Bracket	36
D007	APL-BR-117	Brake Oil Container	36
D008	APL-BR-116	Brake Oil Container	36
D011	APL-BR-103	Roller for Cam Shaft (38-19)	36
D012	APL-BR-104	Fulcrum Pin for Cam Shaft (38-22)	36

Ref. No.	Apel Code	Description	Pg
D013	APL-BR-105	Roller for Cam Shaft (32-19)	36
D014	APL-BR-106	Fulcrum Pin for Cam Shaft (32-25)	36
D015	APL-BR-162	Brake Cam Bush Set (Rear) (TVS)	39
D016	APL-BR-169	Brake Cam Distance Set of 2 Pcs. (TVS)	39
D017	APL-BR-171	Brake Cam Bush Single Collar (Rear)	39
D018	APL-BR-144	Brake Cam Torque Plate Metal Bush	38
D020	APL-BR-153	Brake Cam Shaft Overhauling Kit (TVS)	38
D021	APL-BR-161	Brake Cam Bush Set (Front) (TVS)	39
D022	APL-BR-172	Brake Cam Bush Double Collar	39
D024	APL-BR-125	Slack Adjuster Kit (Slot Type)	37
D025	APL-BR-126	Slack Adjuster Kit (Makhi Type)	37
D026	APL-BR-111	Brake Cam Washer Big (2 mm)	36
D027	APL-BR-112	Brake Cam Washer Big (1 mm)	36
D029	APL-BR-154	Brake Cam Shaft Overhauling Kit (Kalyani)	38
D030	APL-BR-152	Nut & Pin Kit for Brake Chamber Bolt	38
D031	APL-BR-124	Brake Chamber Spring	37
D032	APL-BR-131	Brake Pedal Kit (Minor)	37
D034	APL-BR-101	Pin Kit (Cotter Pin Type)	36
D035	APL-BR-102	Pin Kit (Head Type)	36
D037	APL-BR-127	Slack Adjuster Kit (HALDEX)	37
D038	APL-BR-151	Brake Carrier Bolt	38
D038	APL-FS-147	Brake Carrier Bolt	67
D039	APL-BR-110	Brake Cam Washer & Shims Kit Front/Rear	36
D040	APL-BR-148	Nut & Pin Kit for Brake Chamber Bolt	38
D042	APL-BR-145	Brake Chamber Bolt with Nut and Pin	38
D043	APL-BR-134	Brake Chamber Bracket Set (Rear)	37
D044	APL-BR-149	Brake Chamber Bracket Bolt Set of 2 Pcs.	38
D047	APL-BR-197	Silencer for Air Dryer Assembly	40
D049	APL-BR-133	Brake Chamber Bracket Set (Front)	37
D052	APL-BR-150	Brake Chamber Bracket Bolt Set of 2 Pcs.	38
D053	APL-BR-135	Brake Chamber Bracket Set (Front)	37
D054	APL-BR-136	Brake Chamber Bracket Set (Rear)	37
D055	APL-BR-137	Brake Chamber Bracket (Front)	37
D056	APL-BR-138	Brake Chamber Bracket (Rear)	37
D057	APL-BR-128	Slack Adjuster Kit (Modified)	37
D060	APL-BR-129	Slack Adjuster Kit	37
D061	APL-BR-113	Brake Cam Washer Small (2mm)	36
D062	APL-BR-114	Brake Cam Washer Small (1mm)	36
D063	APL-BR-107	Roller for Cam Shaft (52-19)	36
D064	APL-BR-108	Fulcrum Pin for Cam Shaft (52-22)	36
D065	APL-BR-201	D.D.U. Side Cover	41
D066	APL-BR-202	D.D.U. Top Cover with Fitting Kit	41
D067	APL-BR-198	Silencer for D.D.U. Assembly	40
D068	APL-BR-200	D.D.U. Valve	40
D071	APL-BR-109	Roller for Cam Shaft (35-19)	36
D075	APL-BR-139	Brake Chamber Bracket (TVS) Front	37
D076	APL-BR-140	Brake Chamber Bracket (TVS) Rear	37
D078	APL-BR-141	Brake Chamber Bracket (Rear)	38
D079	APL-BR-146	Brake Chamber Bolt With Nut & Pin	38
D080	APL-BR-199	Silencer Air Dryer Assembly	40
D081	APL-BR-121	Diapharm Knorr T - 20	37
D082	APL-BR-122	Diapharm Knorr T - 24	37
D083	APL-BR-123	Diapharm Knorr T - 30	37
D084	APL-BR-147	Brake Chamber Bolt With Nut & Pin	38
D087	APL-BR-209	Booster Bracket (70 No.)	41
D088	APL-BR-210	Booster Bracket (150 No.)	41
D089	APL-BR-193	DDU Major Kit 3/96	40
D090	APL-BR-194	Air Dryer Major KIT 3/75	40
D093	APL-BR-159	Brake Cam Oil Seal Set of 2 Pcs. (Meritor)	38
D094	APL-BR-155	Brake Cam Shaft Overhauling Kit (Meritor)	38
D095	APL-BR-165	Brake Cam Bush Set (Front) (Meritor)	39
D096	APL-BR-166	Brake Cam Bush Set (Rear) (Meritor)	39
D098	APL-BR-132	Palm Coupling Bush (Trailer)	37
D099	APL-BR-195	DDU Filter 311700	40
D100	APL-BR-196	Air Dryer Filter 311370	40
D101	APL-BR-186	Brake Adjuster with Bolt	40

Ref. No.	Apel Code	Description	Pg
D102	APL-BR-191	Brake Adjuster with Bolt	40
D103	APL-BR-208	Brake Shoe Adjusting Kit (Front/ Rear)	41
D104	APL-BR-192	Brake Adjuster with Bolt	40
D105	APL-BR-187	Brake Adjuster with Bolt Modified	40
D106	APL-BR-188	Brake Adjuster with Bolt Modified	40
D107	APL-BR-212	Servo Non Return Valve with Grommet	41
D108	APL-BR-205	Brass Connector 10 X 10 mm	41
D110	APL-BR-189	Vacuum Brake Valve Seal Kit	40
D110	APL-BR-190	Vacuum Brake Valve Seal Kit	40
D112	APL-BR-156	Brake Cam Shaft Kit	38
D115	APL-BR-160	Brake Cam Oil Seal Set of 2 Pcs.	38
D117	APL-BR-167	Brake Cam Bush (Brass) Set of 2 Pcs.	39
D118	APL-BR-170	Brake Cam Distance Set of 2 Pcs.	39
D119	APL-BR-168	Brake Cam Bush (Brass) Set of 2 Pcs.	39
D123	APL-BR-203	Conversion Tee (12 mm to 10 mm)	41
D124	APL-BR-204	Conversion Tee (10 mm to 12 mm)	41
D125	APL-BR-142	Brake Chamber Bracket (Front)	38
D126	APL-BR-143	Brake Chamber Bracket (Rear)	38
D131	APL-BR-130	Slack Adjuster Kit	37
D135	APL-BR-118	Brake Oil Container	36
D136	APL-BR-119	Brake Oil Container with Sensor	36
D137	APL-BR-120	Brake Oil Container with Sensor	36
D145	APL-BR-206	Brass Connector 12 X 12 mm	41
D146	APL-BR-207	Brass Connector 10 X 12mm	41
D150	APL-BR-211	Booster Bracket (90 No.)	41
D151	APL-BR-179	Brake Shoe Return Spring	39
D152	APL-BR-180	Brake Shoe Return Spring	39
D153	APL-BR-185	Brake Shoe Retaining Spring	40
D201	APL-BR-173	Brake Shoe Return Spring (BIL)	39
D202	APL-BR-174	Brake Shoe Return Spring (BIL)	39
D203	APL-BR-175	Brake Shoe Return Spring (AAL)	39
D204	APL-BR-176	Brake Shoe Return Spring (Meritor)	39
D205	APL-BR-177	Brake Shoe Spring	39
D206	APL-BR-178	Brake Shoe Spring	39
D211	APL-BR-181	Brake Shoe Retaining Spring (BIL)	40
D212	APL-BR-182	Brake Shoe Retaining Spring (AAL)	40
D213	APL-BR-183	Brake Shoe Retaning Spring (BIL)	40
D214	APL-BR-184	Brake Shoe Spring	40
E001	APL-AC-109	Accelerator End (Gold)	42
E003	APL-AC-117	Accelerator Spring	42
E005	APL-AC-113	Accelerator End	42
E007	APL-AC-103	Accelerator Pedal	42
E008	APL-AC-101	Accelerator Pedal Assembly	42
E009	APL-AC-102	Accelerator Pedal Assembly	42
E010	APL-AC-107	Accelerator Pedal Assembly (Sensor)	42
E011	APL-AC-118	Accelerator Spring	42
E012	APL-AC-119	Accelerator Spring (Rotary Pump)	42
E015	APL-AC-116	Accelerator Cable Lock	42
E021	APL-AC-108	Accelerator Pedal Assy (Sensor)	42
E102	APL-AC-110	Accelerator End (Right) (Gold)	42
E103	APL-AC-112	Accelerator Control Fork & Link Kit	42
E104	APL-AC-111	Accelerator End (Left) (Gold)	42
E105	APL-AC-114	Accelerator End (Right)	42
E106	APL-AC-115	Accelerator End (Left)	42
E107	APL-AC-104	Accelerator Pedal	42
E108	APL-AC-105	Accelerator Pedal Assembly	42
E109	APL-AC-106	Accelerator Pedal Assembly	42
E111	APL-AC-120	Accelerator Spring	42
F003	APL-DF-116	Differential Shims Kit	43
F004	APL-GR-110	Magnetic Drain Plug for Gear Box &	19
F006	APL-DF-133	Pinion Nut	44
F049	APL-DF-134	Input Shaft Nut	44
F052	APL-DF-148	Air Breather Assembly	45
F081	APL-DF-160	Pinion Spacer	45
F215	APL-DF-136	Pinion Nut	44
F217	APL-DF-129	Thru Shaft (C34 X 32)	44

Ref. No.	Apel Code	Description	Pg
F218	APL-DF-135	Thru Shaft Nut	44
F219	APL-DF-125	Cage, Cup & Cone Assembly with Oil Seal	44
F221	APL-DF-128	Air Chamber Assembly with hardware	44
F223	APL-DF-153	Magnetic Drain Plug	45
F224	APL-DF-154	Magnetic Drain Plug	45
F225	APL-DF-155	Filler Plug	45
F226	APL-DF-156	Magnetic Drain Plug	45
F227	APL-DF-130	Thru Shaft (C39 X 20)	44
F229	APL-DF-126	Cage, Cup & Cone Assembly with Oil Seal	44
F231	APL-DF-106	Input Shaft Oil Seal	43
F232	APL-DF-105	Thru Shaft Oil Seal	43
F233	APL-DF-107	Input Shaft Oil Seal (Rear)	43
F234	APL-DF-115	Input Shaft Oil Seal (Rear)	43
F236	APL-DF-114	Input Shaft Oil Seal	43
F237	APL-DF-104	Input Shaft Oil Seal Set of 3 Pcs.	43
F238	APL-DF-113	Thru Shaft Oil Seal	43
F239	APL-DF-108	Thru Shaft Oil Seal	43
F240	APL-DF-112	Pinion Oil Seal	43
F241	APL-DF-131	Thru Shaft (C26 X 35)(SRT Axle)	44
F242	APL-DF-132	Thru Shaft (C39 X 34) DANA SPICER	44
F251	APL-DF-137	Input Shaft Nut	44
F252	APL-DF-138	Pinion Nut	44
F253	APL-DF-139	Input Shaft Washer	44
F254	APL-DF-140	Input Shaft Washer (SRT Axle)	44
F261	APL-DF-101	Thru Shaft Kit	43
F262	APL-DF-102	Input Shaft Kit	43
F263	APL-DF-103	Input Shaft Kit Rear	43
F264	APL-DF-109	Thru Shaft Kit	43
F265	APL-DF-110	Input Shaft Kit	43
F266	APL-DF-111	Input Shaft Kit Rear	43
F271	APL-DF-117	Thru Shaft Kit	43
F272	APL-DF-118	Pinion Kit (Forward)	43
F273	APL-DF-119	Pinion Kit (RWD)	43
F274	APL-DF-120	Input Shaft Kit	43
F351	APL-DF-121	Cage Cup & Cone Assembly -	44
F352	APL-DF-122	Cage Cup & Cone Assembly - Input Shaft	44
F353	APL-DF-123	Cage Cup & Cone Assembly - Pinion	44
F356	APL-DF-124	Cage Cup & Cone Assembly - Input Shaft	44
F360	APL-DF-127	Cage Cup & Cone Assembly - Thru Shaft	44
F361	APL-DF-149	Nest Assembly (41 Teeth)	45
F362	APL-DF-150	Nest Assembly (Inter Axle)(22 Teeth)	45
F367	APL-DF-151	Nest Assembly (Differential)(37 Teeth)	45
F371	APL-DF-141	Side Gear Inter Axle (16 X 32)	45
F372	APL-DF-142	Side Gear Inter Axle(16X20)	45
F376	APL-DF-143	Side Gear Inter Axle (16 X 35)	45
F377	APL-DF-145	Side Gear Inter Axle (16 X21)	45
F378	APL-DF-144	Side Gear Inter Axle (16 X 35)	45
F379	APL-DF-147	Side Gear Inter Axle (16 X21)	45
F380	APL-DF-146	Side Gear Inter Axle (16 X21)	45
F381	APL-DF-157	Clutch Collar (28 Teeth)	45
F382	APL-DF-158	Clutch Collar (15 Teeth)	45
F386	APL-DF-159	Clutch Collar (21 Teeth)	45
F394	APL-DF-152	Oil Pump (SRT Axle)	45
G002	APL-ST-146	Steering Plate (VRST)(3 Hole)	48
G003	APL-ST-147	Steering Plate (4 Hole)	48
G007	APL-ST-124	Steering Arm Top	47
G008	APL-ST-121	Steering Arm RH	47
G009	APL-ST-122	Steering Arm LH	47
G010	APL-ST-123	Steering Arm Top	47
G012	APL-ST-125	Steering Arm RH	47
G013	APL-ST-126	Steering Arm LH	47
G014	APL-ST-127	Steering Arm Top	47
G015	APL-ST-149	Power Steering Bracket (3716)	48
G016	APL-ST-150	Power Steering Bracket (3711)	48
G017	APL-ST-151	Power Steering Bracket (3724)	48
G018	APL-ST-109	Power Steering Pump Bolt	46

Ref. No.	Apel Code	Description	Pg
G019	APL-ST-110	Power Steering Pump Bolt	46
G041	APL-ST-128	Tie Rod Arm RH (Lift Axle)	47
G042	APL-ST-132	Tie Rod Arm LH (Lift Axle)	47
G043	APL-ST-137	Tie Rod Arm RH	47
G044	APL-ST-138	Tie Rod Arm LH	47
G045	APL-ST-139	Steering Arm	47
G055	APL-ST-115	Power Steering Oil Gage	46
G056	APL-ST-116	Power Steering Oil Gage	46
G057	APL-ST-136	Power Steering Bolt (M18 X 50)	47
G080	APL-ST-108	Reservoir Tank Assembly RANE	46
G081	APL-ST-105	Reservoir Tank Assembly	46
G083	APL-ST-106	Reservoir Tank Assembly (Thread)	46
G085	APL-ST-104	Reservoir Tank Assembly RANE	46
G088	APL-ST-101	Reservoir Tank Assembly	46
G089	APL-ST-102	Reservoir Tank Assembly	46
G090	APL-ST-103	Reservoir Tank Assembly	46
G096	APL-ST-113	Power Steering Pump Bracket	46
G097	APL-ST-114	Power Steering Pump Bracket	46
G102	APL-ST-148	Steering Plate	48
G103	APL-ST-144	Power Steering Bracket	48
G105	APL-ST-145	Power Steering Bracket	48
G108	APL-ST-129	Steering Arm RH	47
G109	APL-ST-130	Steering Arm LH	47
G110	APL-ST-131	Steering Arm	47
G118	APL-ST-133	Tie Rod Arm RH	47
G119	APL-ST-134	Tie Rod Arm LH	47
G120	APL-ST-135	Steering Arm	47
G202	APL-ST-111	Steering Adjusting Kit	46
G207	APL-ST-117	Steering Sector Shaft Oil Seal (Big)	46
G208	APL-ST-118	Steering Worm Shaft Oil Seal (Small)	46
G209	APL-ST-119	Steering Sector Shaft Oil Seal (Big)	46
G210	APL-ST-120	Steering Worm Shaft Oil Seal (Small)	46
G222	APL-ST-112	Steering Adjusting Kit	46
G226	APL-ST-107	Reservoir Tank Assembly ZF	46
G251	APL-ST-140	Power Steering Bracket (Base Plate)	47
G252	APL-ST-141	Power Steering Bracket (Base Plate)	48
G253	APL-ST-142	Power Steering Bracket	48
G254	APL-ST-143	Power Steering Bracket (Cup Type)	48
H001	APL-AX-101	King Pin Repair Kit	49
H002	APL-AX-102	King Pin Repair Kit	49
H003	APL-AX-103	King Pin Repair Kit	49
H004	APL-AX-120	King Pin Cup	49
H005	APL-AX-104	King Pin Repair Kit	49
H006	APL-AX-111	Front Wheel Axle Shims Kit for	49
H008	APL-AX-112	Front Wheel Axle Shims Kit	49
H053	APL-AX-113	Front Spindle Lock Washer	49
H054	APL-AX-114	Front Spindle Lock Washer	49
H055	APL-AX-115	Front Spindle Lock Washer	49
H056	APL-AX-119	Front Spindle Lock Washer	49
H101	APL-AX-105	King Pin Repair Kit	49
H103	APL-AX-106	King Pin Repair Kit	49
H105	APL-AX-107	King Pin Repair Kit	49
H106	APL-AX-108	King Pin Repair Kit	49
H107	APL-AX-109	King Pin Repair Kit	49
H109	APL-AX-116	Front Wheel Axle Shims Kit for	49
H131	APL-AX-117	Front Spindle Lock Washer	49
H132	APL-AX-118	Front Spindle Lock Washer	49
H201	APL-AX-110	King Pin Repair Kit	49
I002	APL-AX-137	Rear Wheel Axle Shims Kit for	50
I018	APL-AX-133	Locking Bolt for Axle Check Nut	50
I019	APL-AX-134	Locking Bolt for Axle Check Nut	50
I021	APL-AX-138	Rear Wheel Axle Shims Kit for	50
I023	APL-AX-139	Rear Wheel Axle Shims Kit for	50
I024	APL-AX-140	Rear Wheel Axle Shims Kit for	50
I030	APL-AX-129	Lock Washer	50
I032	APL-AX-130	Lock Washer	50

Ref. No.	Apel Code	Description	Pg
I071	APL-AX-125	Ballon Tee	50
I072	APL-AX-126	Lift Axle Rubber Bush	50
I073	APL-AX-127	Lift Axle Pin	50
I074	APL-AX-128	Lift Axle Washer Set of 2 Pcs.	50
I075	APL-AX-121	Kit Bush Assembly Single for Lift Axle	50
I077	APL-AX-122	Kit Bush Assembly Single for Lift Axle	50
I078	APL-AX-123	Kit Bush Assembly For Lift Axle	50
I080	APL-AX-124	Kit Bush Assembly For Lift Axle (27 mm)	50
I107	APL-AX-131	Lock Washer	50
I108	APL-AX-132	Lock Washer	50
I112	APL-AX-135	Rear Wheel Axle Shims Kit for	50
I113	APL-AX-136	Rear Wheel Axle Shims Kit for	50
J001	APL-AX-153	Anti Roll Bar Kit	51
J002	APL-AX-154	Anti Roll Bar Kit	51
J003	APL-AX-155	Anti Roll Bar Kit	51
J011	APL-AX-152	Weveller Rubber Front	51
J012	APL-AX-156	Weveller Rubber Rear	51
J102	APL-AX-141	Anti Roll Bar Kit with Hardware	51
J103	APL-AX-142	Anti Roll Bar Kit with Hardware	51
J112	APL-AX-145	Anti Roll Bar Kit	51
J113	APL-AX-146	Anti Roll Bar Kit	51
J114	APL-AX-143	Anti Roll Bar Kit	51
J115	APL-AX-144	Anti Roll Bar Kit	51
J116	APL-AX-157	Anti Roll Bar Bracket	51
J117	APL-AX-158	Anti Roll Bar Bracket	51
J118	APL-AX-159	Anti Roll Bar Bracket	51
J119	APL-AX-147	Anti Roll Bar Kit	51
J120	APL-AX-148	Anti Roll Bar Kit	51
J121	APL-AX-149	Anti Roll Bar Kit	51
J122	APL-AX-150	Anti Roll Bar Kit	51
J123	APL-AX-151	Anti Roll Bar Kit	51
J131	APL-AX-160	Anti Roll Bar Bracket	51
K004	APL-PS-101	Centre Joint Bracket (Spicer)	52
K008	APL-PS-113	Front Teeth Nut (SPL 90)	52
K010	APL-PS-103	Centre Joint Bracket (Modified)	52
K012	APL-PS-117	Centre Bearing Cup (6211)	52
K013	APL-PS-118	Centre Bearing Cup (88511)	52
K014	APL-PS-102	Centre Joint Bracket (Spicer)	52
K015	APL-PS-112	Centre Bearing Cup (88509)	52
K017	APL-PS-104	Centre Joint Bracket (Modified)	52
K018	APL-PS-105	Centre Joint Bracket (Spicer)	52
K019	APL-PS-107	Centre Joint Bracket (RSB)	52
K020	APL-PS-108	Center Joint Bracket (RSB 590/620)	52
K040	APL-PS-106	Centre Joint Bracket (Spicer)	52
K041	APL-PS-109	Centre Joint Bracket (Spicer)	52
K061	APL-PS-121	Front Teeth Lock Kit (SPL 2055)	53
K062	APL-PS-122	Front Teeth Lock Kit (RSB 590)	53
K063	APL-PS-114	Front Teeth Nut with Washer (SPL 1710)	52
K064	APL-PS-115	Front Teeth Nut (SPL 1550)	52
K065	APL-PS-116	Front Teeth Nut (MSL 2040)	52
K101	APL-PS-119	Centre Bearing Cup (88507)	52
K102	APL-PS-120	Centre Bearing Cup (88508)	52
K103	APL-PS-110	Centre Joint Bracket (Spicer)	52
K104	APL-PS-111	Centre Joint Bracket (Spicer)	52
M007	APL-AP-184	Ferrule Kit 06 mm (14 No.)	58
M008	APL-AP-187	Ferrule Kit 12 mm (22 No.)	58
M009	APL-AP-188	Ferrule Kit 15 mm (27 No.)	58
M010	APL-AP-189	Ferrule Kit 18 mm (32 No.)	58
M011	APL-AP-190	Ferrule Kit 06 mm with Tee (14 No.)	58
M012	APL-AP-193	Ferrule Kit 12mm with Tee (22 No.)	58
M013	APL-AP-194	Ferrule Kit 15 mm with Tee (27 No.)	58
M014	APL-AP-191	Ferrule Kit 08 mm with Tee (17 No.)	58
M015	APL-AP-192	Ferrule Kit 10 mm with Tee (19 No.)	58
M016	APL-AP-183	Air Tank Drain Valve Brass with Washer	58
M018	APL-AP-185	Ferrule Kit 08 mm (17 No.)	58
M019	APL-AP-186	Ferrule Kit 10mm (19 No.)	58

Ref. No.	Apel Code	Description	Pg
M020	APL-AP-195	Ferrule Kit 18 mm with Tee (32 No.)	58
M021	APL-AP-138	Air Pipe Union 12X 12 mm	55
M023	APL-AP-139	Air Pipe Union 12X 16 mm	55
M024	APL-AP-140	Air Pipe Union 12 X 18 mm	55
M026	APL-AP-141	Air Pipe Union 12 X 22 mm	56
M027	APL-AP-158	Air Pipe Union 12 X 12 mm (Long)	56
M031	APL-AP-142	Air Pipe Union 14 X 14mm	56
M032	APL-AP-143	Air Pipe Union 14 X 16 mm	56
M033	APL-AP-144	Air Pipe Union 14 X 18 mm	56
M041	APL-AP-146	Air Pipe Union 16 X 16 mm	56
M042	APL-AP-147	Air Pipe Union 16 X 18 mm	56
M044	APL-AP-148	Air Pipe Union 16 X 22 mm	56
M051	APL-AP-149	Air Pipe Union 18 X 18 mm	56
M052	APL-AP-159	Air Pipe Union 18 X 18 mm (Long)	56
M053	APL-AP-150	Air Pipe Union 18 X 22 mm	56
M054	APL-AP-151	Air Pipe Union 20X 22 mm	56
M055	APL-AP-152	Air Pipe Union 22X22 mm	56
M056	APL-AP-153	Air Pipe Union 22 X 26 mm	56
M057	APL-AP-160	Air Pipe Union 22 X 22 mm (Long)	56
M058	APL-AP-154	Air Pipe Union 20 X 20 mm	56
M059	APL-AP-155	Air Pipe Union 22 X 24 mm	56
M060	APL-AP-156	Air Pipe Union 24 X 24 mm	56
M061	APL-AP-157	Air Pipe Union 26 X 26 mm	56
M066	APL-AP-107	Air Compressor Head Repair Kit (Minor)	54
M067	APL-AP-108	Air Compressor Head Repair Kit (Major)	54
M071	APL-AP-101	Air Compressor Head Repair Kit (Minor)	54
M072	APL-AP-102	Air Compressor Head Repair Kit (Minor)	54
M073	APL-AP-103	Air Compressor Head Repair Kit (Minor)	54
M074	APL-AP-104	Air Compressor Head Repair Kit (Minor)	54
M076	APL-AP-114	Air Compressor Head Repair Kit (Major)	54
M077	APL-AP-115	Air Compressor Head Repair Kit (Major)	54
M078	APL-AP-116	Air Compressor Head Repair Kit (Major)	54
M091	APL-AP-176	Air Pipe Tee 3 Way 12 X 12 X 12mm	57
M093	APL-AP-177	Air Pipe Tee 3 Way 16 X 16 X 16 mm	57
M094	APL-AP-178	Air Pipe Tee 3 Way 18 X 18 X 18 mm	57
M095	APL-AP-179	Air Pipe Tee 3 Way 18 X 22 X 22mm	57
M096	APL-AP-180	Air Pipe Tee 3 Way 22 X 22 X 22mm	57
M097	APL-AP-181	Air Pipe Tee 3 Way 18 X 18 X 22 mm	58
M098	APL-AP-182	Air Pipe Tee 3 Way 26 X 26 X 26 mm	58
M103	APL-AP-117	Air Compressor Head Repair Kit (Major)	54
M104	APL-AP-105	Air Compressor Head Repair Kit (Minor)	54
M105	APL-AP-106	Air Compressor Head Repair Kit (Minor)	54
M106	APL-AP-118	Air Compressor Head Repair Kit (Major)	54
M151	APL-AP-165	Adopter with 'O' Ring 16 X 22 mm	57
M152	APL-AP-166	Adopter with 'O' Ring 18 X 22 mm	57
M153	APL-AP-167	Adopter with 'O' Ring 26 X 26 mm	57
M163	APL-AP-168	Elbow 18 X 18 mm	57
M164	APL-AP-169	Elbow 22 X 22 mm for A. C. Head	57
M165	APL-AP-170	Elbow 18 X 22 mm	57
M166	APL-AP-171	Elbow 26 X 26 mm	57
M167	APL-AP-172	Elbow 26 X 22 mm for A. C. Head	57
M168	APL-AP-173	Elbow 12X 12 mm	57
M169	APL-AP-174	Elbow 12 X 22mm	57
M170	APL-AP-175	Elbow 12 X 18 mm	57
M171	APL-AP-119	Voss Fitting Kit 22 X 1.5 X 6	54
M173	APL-AP-126	Voss Fitting Kit 22 X 1.5 X 10	55
M174	APL-AP-130	Voss Fitting Kit 22 X 1.5 X 12	55
M175	APL-AP-134	Voss Fitting Kit 22 X 1.5 X 15	55
M176	APL-AP-120	Voss Fitting Kit 16 X 1.5 X6	54
M177	APL-AP-123	Voss Fitting Kit 16 X 1.5 X8	55
M178	APL-AP-127	Voss Fitting Kit 16 X 1.5 X 10	55
M179	APL-AP-131	Voss Fitting Kit 16 X 1.5 X 12	55
M180	APL-AP-135	Voss Fitting Kit 16 X 1.5 X 15	55
M181	APL-AP-121	Voss Fitting Kit 22 X 1.5 X 6 'L' Type	55
M182	APL-AP-132	Voss Fitting Kit 22 X 1.5 X 12 'L' Type	55
M183	APL-AP-124	Voss Fitting Kit 22 X 1.5 X 8 'L' Type	55

Ref. No.	Apel Code	Description	Pg
M184	APL-AP-128	Voss Fitting Kit 22 X 1.5 X 10 'L' Type	55
M185	APL-AP-136	Voss Fitting Kit 22 X 1.5 X 15 'L' Type	55
M186	APL-AP-122	Voss Fitting Kit 16 X 1.5 X 6 'L' Type	55
M187	APL-AP-133	Voss Fitting Kit 16 X 1.5 X 12 'L' Type	55
M188	APL-AP-125	Voss Fitting Kit 16 X 1.5 X 8 'L' Type	55
M189	APL-AP-129	Voss Fitting Kit 16 X 1.5 X 10 'L' Type	55
M190	APL-AP-137	Voss Fitting Kit 16 X 1.5 X 15 'L' Type	55
M191	APL-AP-161	Voss Fitting Kit (Thread) 22 X 1.5 X 12	57
M192	APL-AP-162	Voss Fitting Kit (Thread) 22 X 1.5 X 18	57
M196	APL-AP-163	Voss Fitting Kit (Thread) 16 X 1.5 X 12	57
M197	APL-AP-164	Voss Fitting Kit (Thread) 16 X 1.5 X 18	57
M221	APL-AP-110	Water Cooler Head Repair Kit (Silicon)	54
M222	APL-AP-111	Air Compressor Head Repair Kit (Silicon)	54
M223	APL-AP-112	Air Compressor Head Repair Kit (Silicon)	54
M224	APL-AP-113	Air Compressor Head Repair Kit	54
M1075	APL-AP-109	Water Cooler Head Repair Kit (Silicon)	54
N001	APL-FU-110	Feed Pump Valve & Spring Kit of 4 Pcs.	59
N002	APL-FU-111	Feed Pump Repair Kit	59
N005	APL-FU-109	Pre-Filter Nylon Strainer (Glass Filter)	59
N016	APL-FU-101	Air Breather Big	59
N018	APL-FU-112	Hand Primer Repair Kit	59
N026	APL-FU-105	Sealing Bolt for Diesel Tank	59
N027	APL-FU-113	Pre-Filter Glass (Aluminium)	59
N034	APL-FU-106	Diesel Filter Plate Top (10 mm)	59
N035	APL-FU-107	Diesel Filter Plate Top (12 mm)	59
N036	APL-FU-108	Diesel Filter Plate Bottom	59
N050	APL-FU-102	Pump Switch 24V	59
N051	APL-FU-103	Pump Switch 12 V	59
N052	APL-FU-104	Pump Switch 12V	59
O002	APL-EL-101	Gear Lever Boot (Liplype)	60
O003	APL-EL-102	Gear Lever Boot (Zip Type)	60
O004	APL-EL-103	Gear Lever Boot	60
O005	APL-EL-104	Gear Lever Boot	60
O007	APL-EL-128	Gear Lever Sleeve	61
O008	APL-EL-108	Gear Knob (PU)	60
O009	APL-EL-109	Gear Knob (Plastic)	60
O011	APL-EL-105	Diesel Filter Switch	60
O012	APL-EL-110	Gear Knob 6 Gear	60
O013	APL-EL-111	Gear Knob 7 Gear	60
O014	APL-EL-112	Gear Knob 9 Gear	60
O016	APL-EL-106	Diesel Filter Switch	60
O017	APL-EL-107	Diesel Filter Switch	60
O019	APL-EL-116	Alternator Bracket	60
O020	APL-EL-117	Alternator Bracket	60
O021	APL-EL-118	Alternator Bracket	60
O031	APL-EL-126	Alternator Bracket	61
O032	APL-EL-127	Alternator Bracket	61
O051	APL-EL-113	Gear Knob (Gear Shift Cable)	60
O052	APL-EL-114	Gear Knob (Gear Shift Cable)	60
O101	APL-EL-120	Alternator Bracket	60
O102	APL-EL-121	Alternator Bracket	61
O103	APL-EL-122	Alternator Bracket	61
O105	APL-EL-123	Alternator Bracket	61
O106	APL-EL-124	Alternator Bracket	61
O107	APL-EL-125	Alternator Bracket	61
O111	APL-EL-119	Alternator Bracket	60
O115	APL-EL-115	Gear Knob (Gear Shift Cable)	60
P001	APL-DR-133	Grill Knob	63
P002	APL-DR-134	Grill Knob Lock	63
P003	APL-DR-155	Engine Hood Clip Set of 2 Pcs.	64
P006	APL-DR-135	Grill Knob (Backlite) with Lock	63
P007	APL-DR-140	Bonnet Stopper	63
P010	APL-DR-141	Door Hinge Set Of 2 Pcs.	64
P011	APL-DR-122	Grab Handle (White) with Kit	63
P012	APL-DR-123	Grab Handle (Chrome) with Kit	63
P013	APL-DR-138	Door Locking Handle	63

Ref. No.	Apel Code	Description	Pg
P101	APL-DR-148	Bonnet Lock Assembly Lower	64
P102	APL-DR-149	Bonnet Lock Assembly Centre	64
P104	APL-DR-146	Door Lock Catcher	64
P105	APL-DR-158	Striker Bolt with Nut (10mm)	64
P107	APL-DR-117	Door Lock Spring	62
P108	APL-DR-128	R.C. Handle Assembly (RH) Set of 2 Pcs.	63
P109	APL-DR-129	R.C. Handle Assembly (LH) Set of 2 Pcs.	63
P113	APL-DR-130	R.C. Handle Assembly (RH) Set of 2 Pcs.	63
P114	APL-DR-131	R.C. Handle Assembly (LH) Set of 2 Pcs.	63
P115	APL-DR-156	Door Striker Plate with Pin & Screw	64
P116	APL-DR-157	Door Striker Plate with Pin & Screw	64
P117	APL-DR-152	Door Glass Holder Patty with Fitting Kit	64
P118	APL-DR-126	Regulator Glass Handle Set of 2 Pcs.	63
P119	APL-DR-153	Assembly Handle	64
P120	APL-DR-127	Regulator Glass Handle Set of 2 Pcs.	63
P121	APL-DR-101	Door Lock Assembly with Fitting Kit	62
P122	APL-DR-102	Door Lock Assembly with Fitting Kit	62
P123	APL-DR-107	Door Winder Assembly (Right)	62
P124	APL-DR-108	Door Winder Assembly (Left)	62
P125	APL-DR-105	Door Winder Assembly (Right)	62
P126	APL-DR-106	Door Winder Assembly (Left)	62
P127	APL-DR-144	Assembly Bonnet Hinge (Right)	64
P128	APL-DR-145	Assembly Bonnet Hinge (Left)	64
P129	APL-DR-150	Bonnet Spring Upper	64
P130	APL-DR-151	Bonnet Hook Lower	64
P131	APL-DR-120	Door Locking Handle	62
P132	APL-DR-121	Door Non Locking Handle	63
P133	APL-DR-103	Door Lock Assembly (Right)	62
P134	APL-DR-104	Door Lock Assembly (Left)	62
P135	APL-DR-109	Door Winder Assembly (Right)	62
P136	APL-DR-110	Door Winder Assembly (Left)	62
P137	APL-DR-136	Glove Box Lock Assembly with Key	63
P138	APL-DR-139	Door Hinges Bush (Nylon)	63
P139	APL-DR-147	Striker Plate	64
P141	APL-DR-124	Door Locking Handle (Right)	63
P142	APL-DR-125	Door Locking Handle (Left)	63
P143	APL-DR-132	R.C. Handle Assembly Set of 2 Pcs.	63
P145	APL-DR-137	Quarter Glass Lock Assembly Set of 2 Pcs	63
P159	APL-DR-154	Door Glass Holder Patty Assembly	64
P160	APL-DR-159	Striker Bolt with Nut (8mm)	64
P161	APL-DR-111	Door Winder Assembly (Right)	62
P162	APL-DR-112	Door Winder Assembly (Left)	62
P165	APL-DR-142	Door Hinge Set of 4 Pcs. (Spring Type)	64
P166	APL-DR-143	Door Hinge Set of 4 Pcs.	64
P171	APL-DR-113	Door Lock Assembly (Right)	62
P172	APL-DR-114	Door Lock Assembly (Left)	62
P173	APL-DR-115	Door Winder Assembly (Right)	62
P174	APL-DR-116	Door Winder Assembly (Left)	62
P183	APL-DR-118	Door Winder Assembly (Right)	62
P184	APL-DR-119	Door Winder Assembly (Left)	62
R001	APL-FS-101	Cylinder Head Stud with Nut	65
R002	APL-FS-102	Cylinder Head Hex Nut	65
R007	APL-FS-141	Rocker Arm Bolt	67
R008	APL-FS-129	Chamber Stud with Nut	66
R010	APL-FS-113	Fly Wheel Bolt	65
R016	APL-FS-125	Connecting Rod Bolt	66
R019	APL-FS-140	Timing Bolt	66
R020	APL-FS-103	Main Bearing Cap Bolt	65
R021	APL-FS-104	Cylinder Head Bolt	65
R022	APL-FS-131	Main Bearing Cap Bolt	66
R031	APL-FS-121	Stud with Nut (M8 X 35)	66
R032	APL-FS-122	Stud with Nut (M8 X 40)	66
R033	APL-FS-123	Stud with Nut (M8 X 50)	66
R034	APL-FS-124	Stud with Nut (M8 X 60)	66
R041	APL-FS-117	Fuel Pump Stud with Nut	65
R071	APL-FS-164	Axle Lift Bolt (M24 X 150)	68

Ref. No.	Apel Code	Description	Pg
R072	APL-FS-165	Axle Lift Bolt (M24 X 190)	68
R073	APL-FS-167	Axle Lift Bolt (M24 X 210)	68
R074	APL-FS-168	Axle Lift Bolt (M24 X 220)	68
R075	APL-FS-166	Axle Lift Bolt (M24 X 200)	68
R081	APL-FS-169	Axle Lift Bolt (M27 X 190)	68
R082	APL-FS-170	Axle Lift Bolt (M27 X 200)	68
R083	APL-FS-171	Axle Lift Bolt (M27 X 210)	68
R084	APL-FS-172	Axle Lift Bolt (M27 X 220)	68
R105	APL-FS-145	Axle Stud Std. Size	67
R107	APL-FS-146	Axle Stud Std. Size	67
R115	APL-FS-111	Cylinder Head Bolt	65
R116	APL-FS-126	Connecting Rod Bolt	66
R201	APL-FS-132	Cylinder Block Bolt	66
R202	APL-FS-105	Cylinder Head Bolt (M12 X 70)	65
R203	APL-FS-106	Cylinder Head Bolt (M12 X 110)	65
R204	APL-FS-107	Cylinder Head Bolt (M12 X 120)	65
R205	APL-FS-108	Cylinder Head Bolt (M12 X 180)	65
R209	APL-FS-154	Timing Housing Gear Screw (M8 X 50)	67
R210	APL-FS-149	Timing Cover Screw (M8 X 16)	67
R211	APL-FS-150	Valve Cover Screw (M8 X 22)	67
R212	APL-FS-151	Manifold Intake Cover Screw (M8 X 25)	67
R213	APL-FS-142	Cam Follower Cover Screw (M8 X 16)	67
R214	APL-FS-156	Air Intake Connection Screw (M8 X 80)	67
R215	APL-FS-127	Connecting Rod Bolt	66
R216	APL-FS-163	Damper Vibration Bolt (M12 X 36)	68
R218	APL-FS-155	Rocker Lever Support Bolt (M8 X 75)	67
R219	APL-FS-118	Fuel Pump Stud with Nut	65
R220	APL-FS-119	Turbo Charger Stud with Nut	65
R221	APL-FS-159	Exhaust Manifold Bolt (M10 X65)	67
R222	APL-FS-153	Fan Support Bolt (M8 X 40)	67
R223	APL-FS-157	Fan Pulley Bolt (M10 X20)	67
R224	APL-FS-143	Viscous Fan Screw	67
R225	APL-FS-137	Weight Bolt (Small)	66
R226	APL-FS-138	Weight Bolt (Medium)	66
R227	APL-FS-133	Starter Bolt	66
R228	APL-FS-134	Starter Bolt (Pump)	66
R229	APL-FS-144	Water Pump Screw (M8 X 22)	67
R230	APL-FS-162	Water Inlet Bolt (M10 X 75)	68
R231	APL-FS-160	Exhaust Manifold Bolt (M10 X 70)	67
R232	APL-FS-158	Air Compressor Bolt (M10 X 25)	67
R233	APL-FS-161	Belt Tensioner Bolt (M10 X 72)	68
R234	APL-FS-120	Air Compressor Stud with Nut	65
R235	APL-FS-135	Air Compressor Bolt (Big)	66
R236	APL-FS-136	Air Compressor Bolt (Small)	66
R239	APL-FS-139	Weight Bolt (Big)	66
R240	APL-FS-152	Valve Cover Bolt (M8 X 35)	67
R251	APL-FS-114	Fly Wheel Bolt	65
R252	APL-FS-112	Fly Wheel Housing Bolt	65
R253	APL-FS-116	Clutch Cover Assembly Bolt	65
R254	APL-FS-148	Clutch Cover Assembly Bolt	67
R301	APL-FS-109	Cylinder Head Bolt	65
R302	APL-FS-110	Cylinder Head Bolt	65
R304	APL-FS-128	Connecting Rod Bolt	66
R308	APL-FS-130	Chamber Screw	66
R311	APL-FS-115	Fly Wheel Bolt	65
RF006	APL-EN-433		17
RF007	APL-EN-434		17
RF022	APL-EN-435		17
RF023	APL-EN-436		17
RF052	APL-EN-437		17
RF053	APL-EN-438		17
RF054	APL-EN-439		17
RF055	APL-EN-440		17
RF056	APL-EN-441		18
RF057	APL-EN-442		18
RF058	APL-EN-443		18

Ref. No.	Apel Code	Description	Pg
RF059	APL-EN-445		18
RF060	APL-EN-444		18
RF061	APL-EN-446		18
RF062	APL-EN-447		18
RF063	APL-EN-448		18
RF067	APL-EN-449		18
RF104	APL-EN-450		18
RF105	APL-EN-451		18
RF110	APL-EN-452		18
RF121	APL-EN-453		18
RF122	APL-EN-454		18
RF123	APL-EN-455		18
RF124	APL-EN-456		18
RF125	APL-EN-457		18
RF151	APL-EN-458		18
RF152	APL-EN-459		18
RF302	APL-EN-425		17
RF305	APL-EN-426		17
RF306	APL-EN-427		17
RF307	APL-EN-428		17
RF308	APL-EN-429		17
RF311	APL-EN-430		17
RF312	APL-EN-431		17
RF323	APL-EN-432		17
T001	APL-MS-131	Stepney Cable	72
T002	APL-MS-124	Battery Clamp Rod Set	72
T004	APL-MS-121	Centre Joint Bracket Clamp	72
T005	APL-MS-129	Stepney Cable	72
T009	APL-MS-115	Centre Joint Bracket	71
T010	APL-MS-116	Centre Joint Bracket	71
T014	APL-MS-103	Alternator Adjuster Assembly -	71
T015	APL-MS-105	Alternator Adjuster Assembly (12 mm)	71
T016	APL-MS-117	Fuel Tank Cap with Lock	71
T018	APL-MS-111	Alternator Adjusting Bolt with Spring	71
T020	APL-MS-132	Stepney Cable	72
T021	APL-MS-137	Suction Tube Assembly 165 Litres	72
T023	APL-MS-139	Suction Tube Assembly 350 Litres	72
T024	APL-MS-138	Suction Tube Assembly 165 Litres	72
T025	APL-MS-112	Mesh (Jhally) for Suction Tube	71
T026	APL-MS-118	Fuel Tank Cap Lock	71
T027	APL-MS-119	Fuel Tank Cap Lock without Clip	71
T029	APL-MS-140	Suction Tube Assembly 400 Litres	72
T032	APL-MS-107	Alternator Adjuster Assembly-	71
T034	APL-MS-104	Alternator Adjuster Assembly -	71
T035	APL-MS-130	Stepney Cable (Gold)	72
T040	APL-MS-125	Cabin Mounting Kit (M12 X 110)	72
T041	APL-MS-134	Cabin Mounting	72
T042	APL-MS-127	Cabin Mounting Rubber	72
T043	APL-MS-128	Cabin Mounting Rubber Apple	72
T045	APL-MS-126	Cabin Mounting Kit (M12X125)	72
T049	APL-MS-122	Centre Joint Bracket Clamp (Spicer)	72
T050	APL-MS-123	Centre Joint Bracket Clamp (RSB)	72
T056	APL-MS-133	Hydraulic Cylinder Kit (Tilt Cabin)	72
T064	APL-MS-120	Stepney Gear Lock Kit	71
T067	APL-MS-141	Cabin Mounting Bracket Set (RH/LH)	73
T068	APL-MS-142	Cabin Mounting Bracket Set (RH/LH)	73
T075	APL-MS-113	Assembly Shift Cylinder	71
T077	APL-MS-114	Assembly Shift Cylinder Inside	71
T080	APL-MS-135	Manual Valve Control Assembly	72
T081	APL-MS-153	(165 Ltr)	73
T082	APL-MS-154	(350 Ltr)	73
T083	APL-MS-155	(400 Ltr)	73
T091	APL-MS-156	Air Tank Strap	73
T096	APL-MS-158	Air Cleaner Strap (L)	73
T097	APL-MS-159	Air Cleaner Strap	73
T101	APL-MS-144	Diesel Filter Bracket	73

Ref. No.	Apel Code	Description	Pg
T104	APL-MS-101	Alternator Adjuster Assembly (10 mm)	71
T105	APL-MS-106	Alternator Adjuster Assembly	71
T107	APL-MS-102	Alternator Adjuster Assembly (12 mm)	71
T108	APL-MS-136	Suction Tube Assembly	72
T111	APL-MS-108	Assembly Clamp Rod (Alternator)	71
T112	APL-MS-109	Assembly Clamp Rod (Power Steering)	71
T113	APL-MS-110	Assembly Clamp Rod (Power Steering)	71
T114	APL-MS-157	Fuel Tank Strap	73
T118	APL-MS-151	Cabin Hook (Short)	73
T121	APL-MS-143	Cabin Mounting Bracket	73
T122	APL-MS-152	Cabin Hook (Long)	73
T123	APL-MS-150	Cabin Plate	73
T151	APL-MS-145	Jack Kit (Rubber)	73
T152	APL-MS-146	Jack Kit (PVC)	73
T153	APL-MS-147	Jack Kit (Teflon)	73
T154	APL-MS-148	Jack Kit (Canvas)	73
T155	APL-MS-149	Jack Kit (PU)	73
T301	APL-MS-160		73
T302	APL-MS-161		74
T303	APL-MS-162		74
U001	APL-CB-101	Accelerator Cable (70-62)	69
U002	APL-CB-102	Accelerator Cable (73-69)	69
U003	APL-CB-103	Accelerator Cable (77-71)	69
U004	APL-CB-104	Accelerator Cable (125-113)	69
U005	APL-CB-105	Accelerator Cable (81-77)	69
U006	APL-CB-106	Accelerator Cable (63-58)	69
U007	APL-CB-121	Accelerator Cable (99-95) (Casting End)	70
U008	APL-CB-117	Accelerator Cable (119-115)	69
U009	APL-CB-122	Accelerator Cable (63-57) (Casting End)	70
U010	APL-CB-118	Accelerator Cable (55-50)	69
U011	APL-CB-107	Accelerator Cable (69-58)	69
U012	APL-CB-108	Accelerator Cable (72-58)	69
U013	APL-CB-109	Accelerator Cable (76-65)	69
U015	APL-CB-110	Accelerator Cable (87-82)	69
U016	APL-CB-123	Accelerator Cable (82-75) (Casting End)	70
U017	APL-CB-111	Accelerator Cable (89-82)	69
U018	APL-CB-124	Accelerator Cable (87-82) (Casting End)	70
U021	APL-CB-112	Accelerator Cable (96-79)	69
U022	APL-CB-113	Accelerator Cable (102-96)	69
U023	APL-CB-114	Accelerator Cable (109-99)	69
U024	APL-CB-115	Accelerator Cable (97-92)	69
U026	APL-CB-125	Accelerator Cable (102-95) (Casting End)	70
U027	APL-CB-126	Accelerator Cable (146-142) (Casting End)	70
U028	APL-CB-119	Accelerator Cable (128-123)	69
U029	APL-CB-120	Accelerator Cable (27-22)	69
U030	APL-CB-116	Accelerator Cable (112-97) (Cowl Cabin)	69
U032	APL-CB-127	Accelerator Cable (123-116)	70
U033	APL-CB-128	Accelerator Cable (132-125)	70
U034	APL-CB-129	Accelerator Cable (Speed Governor)	70
U035	APL-CB-130	Accelerator Cable (Speed Governor)	70
U041	APL-CB-134	Stop Cable (75-68)	70
U042	APL-CB-135	Stop Cable (105-88)	70
U043	APL-CB-136	Stop Cable	70
U044	APL-CB-137	Stop Cable	70
U051	APL-CB-138	Stop Cable (94-87)	70
U052	APL-CB-139	Stop Cable (100-92)	70
U053	APL-CB-140	Stop Cable (161-155)	70
U091	APL-CB-131	Bonnet Cable	70
U092	APL-CB-132	Bonnet Cable	70
U151	APL-CB-133	Accelerator Cable	70
VI035	APL-AP-145	Air Pipe Union 14 X 22 mm	56
WS002	APL-MS-163	Wheel Suraksha Kit (Front)	74
WS003	APL-MS-164	Wheel Suraksha Kit (Rear)	74
WS005	APL-MS-165	Wheel Suraksha Kit (Rear)	74
WS011	APL-MS-177	Wheel Suraks	74
WS012	APL-MS-180	Wheel Suraks	74

Ref. No.	Apel Code	Description	Pg
WS021	APL-MS-169	Wheel Suraksha Kit (Front)	74
WS023	APL-MS-170	Wheel Suraksha Kit (Rear)	74
WS024	APL-MS-175	Wheel Suraks	74
WS025	APL-MS-178	Wheel Suraks	74
WS026	APL-MS-179	Wheel Suraks	74
WS027	APL-MS-171	Wheel Suraksha Kit (Rear)	74
WS028	APL-MS-176	Wheel Suraks	74
WS031	APL-MS-172	Wheel Suraksha Kit (Front))	74
WS032	APL-MS-173	Wheel Suraksha Kit (Rear)	74
WS033	APL-MS-174	Wheel Suraksha Kit (Rear)	74
WS051	APL-MS-166	Wheel Suraksha Kit (Front/Rear)	74
WS052	APL-MS-167	Wheel Suraksha Kit (Front/Rear) (6 Wheel)	74
WS054	APL-MS-168	Wheel Suraksha Kit (Front/Rear) (10 Wheel)	74



APEL

PUNE PRODUCTS INDIA

EST. 1986

GSTIN

07AECPJ9274P1ZT

PHONE

+91 98186 01701

+91 93193 15343

ADDRESS

Shop No. 217A/2, Guru Nanak Auto Market,
Kashmere Gate, Delhi - 110006, India

EMAIL

atulkumarjain999@gmail.com

Part codes are Apel Pune's own. Vehicle maker names and classes are given only to identify fitment.

Photographs are for representation. Specifications may change without notice.